



THE NEW AMERICAN MOTORCYCLE™

2004

Kingpin™

 **WARNING**

The engine exhaust from this product contains chemicals known to cause cancer, birth defects or other reproductive harm.

We've created a web site just for YOU!

- Technical tips
- New product introductions
- Event schedules
- Parts and Service Manual information
- Exciting details about The Way Out

Check it out...

www.victory-usa.com



The text, photographs and illustrations used in this manual are based on the most current product information available at the time of publication. Product improvements or other changes may result in differences between this manual and the motorcycle. Polaris Industries reserves the right to make production changes at any time, without notice and without incurring any obligation to make the same or similar changes to motorcycles previously built.



2004 OWNER'S MANUAL

Kingpin™

**VICTORY Motorcycle Division, Polaris Industries Inc.
2100 Highway 55, Medina, Minnesota 55340-9800 Tele: (763) 417-8650 Fax: (763) 542-0599**

Copyright© 2003 Polaris Sales Inc. All rights reserved.

POLARIS, POLARIS THE WAY OUT and VICTORY MOTORCYCLES are registered trademarks of Polaris Industries Inc.
VEGAS and KINGPIN are trademarks of Polaris Industries Inc.
DUNLOP is a registered trademark of Dunlop Tire Corporation. LOCTITE is a registered trademark of LOCTITE Corporation.
Features of VICTORY motorcycles are covered by U.S. Patent Nos.:
D,397,976; D,398,065; D,407,169; D,409,551; D,416,831; D,436,561 with additional patents pending.

FOREWORD

Thank you for choosing a Polaris VICTORY motorcycle!

This owner's manual contains information for the VICTORY KINGPIN motorcycle. Some of the photographs and illustrations used in the manual are generalizations, so your model may be slightly different than what is shown.

If you misplace or damage your owner's manual, you should purchase a replacement copy from an authorized VICTORY dealer. This manual should be considered part of the motorcycle, and it should remain with the motorcycle when it's sold.

If you have questions about the operation or maintenance of the motorcycle after you've read this manual, please contact an authorized VICTORY dealer. To locate the nearest authorized VICTORY dealer, call 1-800-POLARIS and provide the area code or zip code of your location. Visit www.polarisindustries.com for a listing of authorized VICTORY dealers by state, zip code or area code.

Your authorized VICTORY dealer will resolve all issues regarding your motorcycle. If you're not satisfied with the performance of your VICTORY dealer, please contact the Polaris Consumer Service Department at 763-417-8650.

VICTORY motorcycles comply with all federal, state and local safety and emission regulations for the area of intended sale.

TABLE OF CONTENTS

FOREWORD	3
INTRODUCTION	5
SAFETY	6
COMPONENT IDENTIFICATION	30
INSTRUMENTS, FEATURES AND CONTROLS	35
PRE-OPERATION CHECK	47
OPERATION	60
MAINTENANCE	74
MAINTENANCE RECORD	79
CLEANING	131
STORAGE	137
WARRANTIES	141
SPECIFICATIONS	151
IDENTIFICATION NUMBERS	156
INDEX	157

Read the Owner's Manual

Your VICTORY owner's manual contains information that's essential to safe riding and proper maintenance of the motorcycle. Anyone who uses the motorcycle (operators and passengers) must read the owner's manual before riding.

Carefully read and understand the information found in the safety section beginning on page 6. Understand and follow the procedures in your owner's manual to keep your VICTORY motorcycle in top condition on the road or in storage. Bring the manual with you when you ride. Following the precautions and procedures in the manual will add to your enjoyment and keep you riding safely.

WARNING

Failure to follow the safety precautions and operation and maintenance procedures outlined in this manual may result in death or injury (to you or your passenger) or damage to the motorcycle.

SAFETY

Symbols and Terms Used in the Owner's Manual

The following safety signal words and symbols appear throughout the owner's manual. Your safety and the safety of others are involved when these words and symbols are used. Become familiar with their meanings before reading the manual.



The safety alert symbol indicates a potential for personal injury to you or others.

WARNING

The safety alert warning indicates a potential hazard that could result in serious injury or death.

Caution

The safety alert caution indicates a potential hazard that may result in minor personal injury or damage to the motorcycle.

Caution

A caution indicates a situation that may result in damage to the motorcycle.

Notice

A notice highlights important information you must pay attention to.

Safe Riding Practices

WARNING

Improper use of this motorcycle can result in serious injury or death to you, your passenger and others. To minimize the risk of injury, read and understand the information contained in this section before operating the motorcycle. This section contains safety information specific to the VICTORY motorcycle, as well as information about general motorcycle safety. Anyone who uses the motorcycle (operators and passengers) must follow these safety precautions.

Motorcycling has inherent risks. You can minimize those risks, but you can't eliminate them completely. Even if you're an experienced motorcycle operator or passenger, read all of the information in this safety section before operating the motorcycle.

- Your ability to safely operate the motorcycle depends on your judgment and your use of safe riding habits. Take a rider education course from the Motorcycle Safety Foundation or another qualified instructor. The course will help you develop or refresh your expertise in safe riding habits through instruction and riding. For information on Motorcycle Safety Foundation rider education courses in your area, call 1-800-446-9227 or visit their homepage at <http://msf-usa.org>.
- Read and understand all information in this owner's manual. It contains safety information specific to individual components and operations.
- Pay close attention to the motorcycle maintenance requirements in this manual. For additional information or assistance with technical services specified in the manual or required by mechanical circumstances, see the *VICTORY Service Manual* (Part Number 9918961) or your authorized VICTORY Dealer.

SAFETY

Safe Riding Practices

The following design characteristics affect how you should ride the VICTORY motorcycle:

- The motorcycle is designed for on-road use with one rider and one passenger. Do not exceed the gross vehicle weight rating (see the specifications section, beginning on page 152, or the certification label on the steering head). Riding off-road, riding with more than one passenger, or carrying weight exceeding the maximum weight rating can make handling difficult, which could cause loss of control.
- In the first 500 miles, operate the motorcycle according to the break-in procedures described on page 61. Operating the motorcycle without following break-in procedures can result in serious engine damage.
- Some VICTORY motorcycles include saddlebags, a windshield, and a passenger backrest as standard equipment. To maintain stability, be prepared to reduce the operating speed of motorcycles equipped with these accessories.

Safe Riding Practices

Follow these general safe riding practices:

- **Before each ride, make the checks described in the Pre-Operation Check section** beginning on page 47. Operating the motorcycle without completing the pre-operation check may cause damage to the motorcycle or result in an accident.
- Until you're thoroughly familiar with the VICTORY motorcycle and all of its controls, practice riding where there is little or no traffic. Practice riding at a moderate speed on varying road surfaces and under varying weather conditions.
- **Know your skills and limits, and ride within them.**
- Allow only licensed, experienced operators to ride your motorcycle, and then only after they have become familiar with its controls and operation.
- Do not ride when you're fatigued or under the influence of alcohol, prescription drugs, over-the-counter drugs or any other drugs. Fatigue, alcohol and drugs can cause drowsiness, loss of coordination and loss of balance. They can also affect your awareness and judgment.
- If your motorcycle operates abnormally, correct the problem immediately (see the *VICTORY Service Manual* or contact your authorized VICTORY dealer). If you continue to operate a motorcycle in this condition, you are likely to aggravate the initial problem, increase the cost of repairs and threaten your safety.

SAFETY

Safe Riding Practices

- The most common cause of accidents involving a motorcycle and an automobile is the automobile driver's failure to see the motorcycle. Ride defensively, as if you are invisible to other motorists, even in broad daylight. Ride where you're clearly visible to other motorists, and observe their behavior carefully, as they may not see or be aware of you.
- **Be especially cautious at intersections, as these are the most likely places for an accident.**
- To prevent loss of control while operating the motorcycle, keep your hands on the handlebars and your feet on the footrests.
- Obey the speed limit and adjust your speed and riding technique based on road, weather and traffic conditions. As you travel faster, the influence of all other conditions increases, which can affect the motorcycle's stability and increase the possibility of losing control.
- Do not move or operate the motorcycle with the steering locked (with accessory lock), as the severely restricted steering could result in loss of control.
- **Reduce your speed when:**
 - The road has potholes or is otherwise rough or uneven.
 - The road has sand, dirt, gravel or other loose substances on it.
 - The road is wet, icy or oily.
 - The road contains painted surfaces, manhole covers, metal grating, railway crossings or other slippery surfaces.

Safe Riding Practices

- **Reduce your speed when:**
 - The weather is windy, rainy or otherwise causing slippery or rapidly changing conditions.
 - The traffic is heavy, congested, not allowing sufficient space between vehicles or otherwise not flowing smoothly.
 - You are being passed in either direction by a large vehicle that produces a wind blast in its wake.
- **To maximize braking effectiveness, use the front and rear brakes together.** Improper braking may cause loss of control or may not slow the vehicle in time to avoid a collision. Be aware of the following braking facts and practices:
 - The rear brake provides 40% of the motorcycle's stopping power, at most.
 - Consider road conditions before applying the brakes. When the road is wet or rough, or contains loose or other slippery substances, apply the brakes gradually.
 - Bring the motorcycle to the upright position before applying the brakes, and avoid applying the brakes in a corner if at all possible. When the motorcycle is leaning through a corner, the amount of traction available for braking is reduced, increasing the possibility of the tires skidding when the brakes are applied.
- When approaching a curve, choose a speed and lean angle that allows you to pass through the curve in your own lane without applying the brakes. Excessive speed, improper lean angle or braking in a curve can cause loss of control.

SAFETY

Safe Riding Practices

- Ground clearance is reduced when the motorcycle leans. Do not allow components to contact the road surface when leaning the motorcycle in a curve, as this could cause loss of control.
- Retract the sidestand fully before riding. If the sidestand is not fully retracted, it could contact the road surface and cause loss of control.
- Do not tow a trailer. Towing a trailer can make the motorcycle hard to handle, which could cause loss of control.

Carrying a Passenger

To carry a passenger safely, do the following:

- Direct the passenger to hold onto you or the seat strap with both hands and to keep both feet on the passenger footrests. Do not carry a passenger who cannot place both feet firmly on the passenger footrests. A passenger who is not holding on properly, or who cannot reach the passenger footrests, can shift their body erratically, which can make the motorcycle hard to handle and cause loss of control.
- If necessary, adjust the rear shock absorber preload according to the instructions on page 92. Improper preload adjustment can make your motorcycle hard to handle and can cause loss of control.
- Before riding, be sure your passenger knows safe riding procedures. Discuss any safety information unfamiliar to your passenger. A passenger who is unaware of safe riding procedures may distract you or make movements that make the motorcycle hard to handle.
- Adjust your riding style to compensate for the differences in handling, acceleration and braking caused by the additional weight of the passenger. Failure to do so can cause loss of control.

Safe Riding Practices

Protective Apparel

To decrease the risk of injury and increase riding comfort, wear protective riding apparel.

- Wear a Department of Transportation (DOT) or SNELL approved helmet. Some state laws require that you wear an approved helmet. **In accidents involving motorcycles, head injuries are the leading cause of motorcyclist fatalities, and statistics prove that an approved helmet is the most effective protection in preventing or reducing head injuries.**
- Wear eye protection. Some state laws require that you wear eye protection. Eye protection reduces the chance that your vision could be impaired by wind or by airborne particles and objects.
- You and your passenger should wear bright or light colored and/or reflective clothing to improve visibility to other motorists. **A motorist's failure to see or recognize a motorcycle is the leading cause of automobile/motorcycle accidents.**
- Wear gloves, a jacket, heavy boots and long pants to prevent or reduce abrasions, lacerations or burns should the motorcycle fall.
- Wear boots with low heels, as high heels can catch on pedals or footrests. The combination of boots and pants should completely cover legs, ankles and feet, protecting skin from engine and exhaust system heat. The engine and exhaust system get hot soon after the engine is started and stay hot for about half an hour after the engine is turned off.
- Do not wear loose, flowing clothing or long boot laces, as they can catch on handlebars, levers or footrests, or become entangled in the wheels, causing loss of control and serious injury.

SAFETY

Gross Vehicle Weight Rating (GVWR)

Gross vehicle weight is the total combined weight of the motorcycle, the operator and the passenger.

- The weight of the motorcycle includes the motorcycle and all of its fluids, any accessories and their contents, and any additional cargo on the motorcycle.
- The weight of the operator or passenger includes body weight, all apparel and objects in or on apparel.

Examples of calculating GVWR are provided on page 15.

Do not exceed the motorcycle's gross vehicle weight rating. Exceeding the weight rating can reduce stability and handling and could cause loss of control.

Refer to the specifications section of this manual (beginning on page 152) or the certification label on your motorcycle's steering head for model-specific GVWR information.

Example 1: KINGPIN with no accessories or cargo
Gross Vehicle Weight Rating 1170 lbs (531 kg)

Item	Weight
KINGPIN- with full capacity of all fluids	685 lbs (311 kg)
Operator - with recommended riding apparel	220 lbs (100 kg)
Passenger - with recommended riding apparel	155 lbs (70 kg)
Total Weight	1060 lbs (481 kg)

Example 2: KINGPIN with Touring Package and cargo
Gross Vehicle Weight Rating 1170 lbs (531 kg)

Item	Weight
KINGPIN - with full capacity of all fluids	685 lbs (311 kg)
Weight of Touring Package (Hard Bags & Brackets)	33 lbs (15 kg)
Cargo - saddlebags at capacity	14 lbs (6 kg)
Operator - with recommended riding apparel	220 lbs (100 kg)
Passenger - with recommended riding apparel	155 lbs (70 kg)
Total Weight	1107 lbs (502 kg)

NOTE: As shown in Example 2, the weight of any accessory items (touring package or individual items) in addition to the cargo, must be added to the base weight of the KINGPIN. NEVER exceed GVWR. If you have any questions regarding safe loading of your VICTORY motorcycle, please consult an authorized VICTORY dealer.

SAFETY

Carrying Cargo

Use the following guidelines when attaching cargo or accessories to the motorcycle. Where applicable, these guidelines also refer to the contents of any accessories.

- Keep cargo and accessory weight to a minimum, and keep items as close to the motorcycle as possible to minimize a change in the motorcycle's center of gravity. Changing the center of gravity can cause loss of stability and handling and result in loss of control.
- Distribute weight evenly on both sides of the motorcycle. Maintain even weight distribution by checking accessories and cargo to make sure they're securely attached to the motorcycle before riding and whenever you take a break from riding. Uneven weight distribution, or accessories or cargo that shift suddenly while you're riding can make the motorcycle hard to handle and result in loss of control.
- Do not attach large or heavy cargo such as sleeping bags, duffel bags or tents to the handlebars, front fork area or front fender. Cargo or accessories placed in these areas can cause instability (due to improper weight distribution or aerodynamic changes) and can cause loss of control. Such items can also block air flow to the engine and cause overheating that can damage the engine.
- Do not exceed the maximum cargo weight limit of any accessory (see accessory instructions and labels), and do not attach cargo to an accessory not designed for that purpose, as these could result in an accessory failure that could cause loss of control.
- Never mount anything but Victory approved accessories to the highway bar.

Saddlebags


When operating a motorcycle with original equipment or accessory saddlebags:

- Never ride at speeds exceeding 80 mph (120 km/h). Depending on load and weather conditions, the maximum safe operating speed may be less than 80 mph (120 km/h). Saddlebags, combined with the lifting or buffeting effects of wind, can make the motorcycle unstable and cause loss of control.
- Distribute weight evenly in each of the saddlebags.
- Do not exceed the maximum cargo weight limit of the saddlebags. Hard bags (KINGPIN) or accessory leather saddlebags are 7 lbs. (3.2 kg) each.
- Do not exceed the motorcycle's gross vehicle weight rating. Exceeding the weight rating can reduce stability and handling and cause loss of control.

Transporting the Motorcycle

If you must transport the motorcycle:

- Use a truck or trailer. Do not tow the motorcycle with another vehicle, as towing will impair the motorcycle's steering and handling, which can cause loss of control.
- Position and restrain the motorcycle so it remains upright on the truck or trailer, as gasoline may leak out of the fuel tank if the motorcycle leans to one side. Gasoline is a fire hazard and it can also damage the motorcycle's finish.
- Place the transmission in first or second gear.
- Do not restrain the motorcycle using the handlebars. Place tie-downs around the fork tubes above the lower triple clamp. Secure the rear of the motorcycle with tiedowns around the swingarm or rear wheel, being careful to avoid the brake line, exhaust, and drive belt.



SAFETY

Parking the Motorcycle

When leaving the motorcycle unattended, turn the engine off and remove the ignition key. See page 72.

Park the motorcycle where people are not likely to touch the hot engine or exhaust system or place combustible materials in close proximity to these hot areas. Do not park near a flammable source such as a kerosene heater or an open flame, where hot components could ignite combustible materials.

Park the motorcycle on a firm, level surface. Sloped or soft surfaces may not support the motorcycle when it's parked, and it may tip over. If you must park on a slope or soft surface, follow the precautions outlined on page 72.

Modifications

Modifying the motorcycle by removing any equipment or by adding equipment not approved by VICTORY may void your warranty. Such modifications may make the motorcycle unsafe to ride and could result in severe injury to operator or passengers, as well as damage to the motorcycle. Some modifications may also be illegal in some states. If in doubt, contact your authorized VICTORY Dealer.

Accessory Selection and Installation

Because VICTORY cannot test and make specific recommendations concerning every accessory or combination of accessories sold, the operator is responsible for determining that the motorcycle can be safely operated with any accessories or additional weight. Use the following guidelines when choosing and installing accessories:

- Do not install accessories that impair the stability, handling or operation of the motorcycle. Before installing an accessory, be sure that it does not:
 - Reduce ground clearance when the motorcycle is either leaned or in a vertical position.
 - Limit suspension or steering travel or your ability to operate controls.
 - Displace you from your normal riding position.
 - Obscure lights or reflectors.
- Bulky or large accessories can cause instability (due to the lifting or buffeting effects of wind) and loss of control.
- Do not install electrical accessories that exceed the capacity of the motorcycle's electrical system. Never install higher wattage light bulbs than those supplied as original equipment. An electrical failure could result and cause hazardous loss of engine power or lights or damage to the electrical system.
- If you want to add a windshield, backrest or luggage rack, choose one designed and approved by VICTORY specifically for your model. Follow the instructions for proper installation and use. An improperly designed or installed windshield, backrest or luggage rack can reduce stability, causing loss of control.

SAFETY

Gasoline and Exhaust

For complete fueling procedures, see page 63.

Gasoline is highly flammable and can be explosive in certain conditions. Observe the following precautions when you refuel or service the fuel system:

- Turn off the engine.
- Use a well-ventilated area.
- Open the fuel cap slowly.
- Do not spill gasoline on the engine or the exhaust system. Immediately wipe, or rinse with water, gasoline spilled on any part of the motorcycle or the surrounding area.
- Do not smoke while fueling.
- Do not fuel in an area where there are sparks or open flame.

Gasoline and gasoline vapors are poisonous and can cause severe injury. Do not swallow gasoline, inhale gasoline vapors, or spill gasoline on yourself or your clothes. If you swallow gasoline, inhale more than a few breaths of gasoline vapor, or get gasoline in your eyes, see a physician immediately. If you spill gasoline on your skin, wash it off immediately with soap and water. If you spill gasoline on your clothes, change your clothes immediately.

Exhaust gases contain carbon monoxide, a colorless, odorless gas that can cause unconsciousness or severe injury. Observe the following precautions to avoid the effects of exhaust gases:

- Do not inhale exhaust gases.
- Do not start or run the engine in an enclosed area.

Maintenance

Maintain the motorcycle according to the following requirements:

- Before each ride, complete a pre-operation check as outlined beginning on page 47. Operating the motorcycle without completing the pre-operation check can cause damage to the motorcycle or result in an accident.
- Perform periodic maintenance according to the intervals outlined in the Periodic Maintenance Interval tables beginning on page 75. Operating the motorcycle without performing periodic maintenance can damage the motorcycle or result in bodily injury.
- Maintain proper tire pressure and tread condition and proper wheel and tire balance. Inspect tires regularly and replace them if they're worn or damaged. Use only an approved replacement tire and see the *VICTORY Service Manual* or your authorized VICTORY Dealer for tire replacement. Operating the motorcycle with improper tire pressure or tread condition, or improper wheel or tire balance, can make the motorcycle hard to handle and cause loss of control.
- Check proper steering head bearing adjustment. Regularly inspect the rear shock absorber and the front forks. Check for fork oil or shock absorber fluid leaks. Operating the motorcycle with a loose, worn, or damaged steering system or front or rear suspension system can make the motorcycle hard to handle and cause loss of control. To repair steering or suspension system wear or damage, see the *VICTORY Service Manual* or contact your authorized VICTORY Dealer.

SAFETY

Maintenance

- Keep the motorcycle clean. In addition to extending the service life and the original appearance of the motorcycle, a complete and thorough cleaning can reveal items in need of repair. For complete cleaning procedures, see page 131.
- Keep equipment required by federal, state, and local laws in place and in good working condition. Your license plate must be clean, clearly visible in all conditions, and installed in a position specified by law.
- Each fastener used in the motorcycle meets our quality specifications for strength, finish and type. When replacement fasteners are needed, use only genuine VICTORY parts, tightened to the proper torque. A fastener that does not meet original specifications could fail and result in damage to the motorcycle or injury to riders.

Reporting Safety Defects

If you believe that your vehicle has a defect that could result in a crash or cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Polaris Industries in writing.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer or Polaris Industries.


To contact NHTSA, or obtain other information about motor vehicle safety, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393, visit the NHTSA website at www.nhtsa.dot.gov, or write to:

NHTSA
US Department of Transportation
400 7th Street Southwest
Washington, DC 20590

SAFETY

Location of Safety and Vehicle Information Labels

See page 25 for decal type and description.



Location of Safety and Vehicle Information Labels

⚠ WARNING	⚠ AVERTISSEMENT
<ul style="list-style-type: none"> ❑ Read Owner's Manual and, during use, follow all safety precautions. ❑ Always wear an approved helmet, eye protection and protective clothing. ❑ If your Owner's Manual is missing, contact a Victory / Polaris dealer for a replacement. 	<ul style="list-style-type: none"> ❑ Lire le Manuel d'utilisation et suivre toutes les consignes de sécurité durant l'utilisation. ❑ Toujours porter un casque de sécurité approuvé, des lunettes et des vêtements de protection. ❑ Si il n'y a pas de manuel du propriétaire, en demander un auprès d'un concessionnaire Victory/Polaris.
UNLEADED FUEL RECOMMENDED	CARBURANT SANS PLOMB RECOMMANDÉ 7079215

Location A (FUEL WARNING)

Month/Year:

Mfd By: VICTORY MOTORCYCLE DIVISION, Polaris Industries, Inc.
GWR#: _____

MOTORCYCLE

Information on this decal will vary by model, features, and options. Refer to actual decal on the vehicle.

GAWR F:
GAWR R:

THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE.

Location B (MANUFACTURING DATE) Information varies by model

MOTORCYCLE NOISE EMISSION CONTROL INFORMATION	INFORMATIONS SUR LA LUTTE CONTRE LE BRUIT ÉMIS PAR LES MOTOCYCLETTES
<p>THIS 2004 VICTORY MOTORCYCLE WITH EXHAUSTARY NOISE LEVELS OF 191.30 DB(A) IS IN COMPLIANCE WITH THE FEDERAL TEST PROCEDURE. THIS MOTORCYCLE TO EXCEED FEDERAL NOISE STANDARDS ARE PROHIBITED BY FEDERAL LAW. SEE OWNER'S MANUAL.</p> <p>VICTORY MOTORCYCLE POLARIS INDUSTRIES INC. 2103 HWY 55 HAMEL, MN 55340-0800</p>	<p>CEtte MOTOCYCLETTE VICTORY 2004 ÉQUIPÉE D'UN SYSTÈME D'ÉCHAPPEMENT ASM N° 120130, 120132, SATISFAIT AUX EXIGENCES SUR LE NIVEAU DE BRUIT ÉMIS DE LA P.A.M. AMÉRICAINNE. SI LE NIVEAU ÉMIS (DB(A)) LES ÉMIS ÉTAIENT CONFORMES À LA PROCÉDURE FÉDÉRALE, TOUTE INDICATION DE CETTE MOTOCYCLETTE QUI POURRAIT ENTRAÎNER UN DÉPASSEMENT DES NORMES D'ÉMISSION DE BRUIT FÉDÉRALES EST INTERDITE PAR LA LOI FÉDÉRALE. SE RÉFÉRER AU MANUEL D'UTILISATION.</p> <p>VICTORY MOTORCYCLE POLARIS INDUSTRIES INC. 2103 HWY 55 HAMEL, MN 55340-0800</p>

Location C (NOISE EMISSION)

TIRE INFORMATION			
Cold Tire Pressures:			
Up to lbs (kg) Load	Front	psi (kpa)	
	Rear	psi (kpa)	
Up to Maximum Load Capacity	Front	psi (kpa)	
	Rear	psi (kpa)	
Maximum Load Capacity:	(kg)		
Tire Brand/Type:	Front		
	Rear		
Tire Size:	Front		
	Rear		
Minimum Recommended			
Tire Center Tread Depth:	Front		
	Rear		
READ OWNER'S MANUAL			

Location D (TIRE INFORMATION) Information varies by model (under left side cover)


 Engine Identification Number Label

Location E (ENGINE I.D.) (on left crankcase half)

SAFETY

Location of Safety and Vehicle Information Labels

See page 27 for decal type and description.




Location of Safety and Vehicle Information Labels

TURN SIGNAL/ TAIL LIGHT RELAY RELAIS DE FEU DE DIRECTION/ FEU ARRIÈRE		HEADLIGHT/ BRAKE LIGHT RELAY RELAIS DE PHARE/ FEU DE FREINAGE		ENGINE/ ECM RELAY RELAIS DU MOTEUR/ MODULE DE COMMANDE ÉLECTRONIQUE (ECM)	
REAR OF VEHICLE ARRIÈRE DU VÉHICULE					
TURN SIGNAL/ TAIL LIGHT/HORN FEU DE DIRECTION/ FEU ARRIÈRE/KLAXON 15 A		HEADLIGHT/ BRAKE LIGHT PHARE/ FEU DE FREINAGE 15 A		ENGINE/ECM MOTEUR/MODULE DE COMMANDE ÉLECTRONIQUE (ECM) 15 A	
SPARE FUSIBLE DE RECHANGE 15 A		IGNITION/GAUGES ALLUMAGE/ INSTRUMENTS 15 A		FUEL PUMP POMPE À CARBURANT 10 A	
7170962					

Location F

FUSE and RELAY LOCATION

(under side cover, on top of fuse box cover)




FUSE BOX REMOVAL (on base of fuse box)

SAFETY

Location of Safety and Vehicle Information Labels

See page 29 for decal type and description.



Location of Safety and Vehicle Information Labels

Location G (TIRE SAFETY)

▲ WARNING	▲ AVERTISSEMENT
USE ONLY CORRECT SERIES TIRE ON THIS RIM. MOUNT USING TIRE LUBRICANT. DO NOT EXCEED MAXIMUM RECOMMENDED INFLATION PRESSURE TO SEAT BEAD. OTHERWISE TIRE TUBE OR RIM FAILURE COULD RESULT WHICH MAY CAUSE PERSONAL INJURY. SEE OWNER'S MANUAL.	NE MONTER QUE DES PNEUS DE BONNES DIMENSIONS SUR CETTE JANTE. INSTALLER EN UTILISANT DE LA GRAISSE A PNEUS. NE PAS GONFLER A UNE PRESSION SUPERIEURE AU MAXIMUM RECOMMANDE POUR ACCROCHER LE TALON DE PNEU : AUTREMENT, IL POURRAIT Y AVOIR DEFAILLANCE DU PNEU, DE LA CHAMBRE OU DE LA JANTE ET RISQUES DE BLESSURES. SE REPORTER AU MANUEL D'UTILISATION.
	7079024

Location H (EMISSION CONTROL INFORMATION)

VEHICLE EMISSION CONTROL INFORMATION

Victory
MOTORCYCLES
U.S.A.

VICTORY MOTORCYCLE DIVISION, Polaris Industries Inc.
2100 HWY 55
HAMEL, MN 55340-9800

ENGINE DISPLACEMENT: 1507cc
ENGINE FAMILY: 4VMC001.5V92
ENGINE EXHAUST CONTROL SYSTEM: SFI
ENGINE TUNEUP SPECIFICATIONS:
IDLE SPEED: 1600 +/-50 RPM
IGNITION TIMING: PERMANENTLY FACTORY SET
IDLE MIXTURE: EFI CONTROLLED
VALVE CLEARANCE: HYDRAULIC TAPPET, SELF-ADJUSTING
SPARK PLUG: NGK CPR8E9-9 SPARK PLUG GAP: 0.032" (0.8 mm)
FUEL: UNLEADED GASOLINE ONLY; 92 PUMP OCTANE OR HIGHER
OIL: 20W-40

THIS VEHICLE CONFORMS TO USEPA REGULATIONS APPLICABLE TO 2004 MODEL YEAR NEW MOTORCYCLES. 7171187

(49 State Models)

VEHICLE EMISSION CONTROL INFORMATION AND EVAPORATIVE HOSE ROUTING - CALIFORNIA

Victory
MOTORCYCLES
U.S.A.

VICTORY MOTORCYCLE DIVISION, Polaris Industries Inc.
2100 HWY 55
HAMEL, MN 55340-9800

ENGINE DISPLACEMENT: 1507cc
ENGINE FAMILY: 4VMC001.5V92
ENGINE EXHAUST EMISSION CONTROL: SFI
ENGINE TUNEUP SPECIFICATIONS:
IDLE SPEED: 1600 +/-50 RPM
IGNITION TIMING: PERMANENTLY FACTORY SET
IDLE MIXTURE: EFI CONTROLLED
VALVE CLEARANCE: HYDRAULIC TAPPET, SELF-ADJUSTING
SPARK PLUG: NGK CPR8E9-9 SPARK PLUG GAP: 0.032" (0.8 mm)
FUEL: UNLEADED GASOLINE ONLY; 92 PUMP OCTANE OR HIGHER
OIL: 20W-40
EVAPORATIVE SYSTEM HOSE ROUTING DIAGRAM

THIS VEHICLE CONFORMS TO USEPA AND CALIFORNIA REGULATIONS APPLICABLE TO 2004 MODEL YEAR NEW MOTORCYCLES AND IS CERTIFIED TO 1.4 HC GVM ENGINE FAMILY EXHAUST EMISSION STANDARD IN CALIFORNIA. 7171187

(California Models
with catalyst)

VEHICLE EMISSION CONTROL INFORMATION

Victory
MOTORCYCLES
U.S.A.

VICTORY MOTORCYCLE DIVISION, Polaris Industries Inc.
2100 HWY 55
HAMEL, MN, U.S.A. 55340-9800

ENGINE DISPLACEMENT: 1507cc
ENGINE FAMILY: 4VMC001.5V92
ENGINE EXHAUST CONTROL SYSTEMS: SFI
ENGINE TUNEUP SPECIFICATIONS:
IDLE SPEED: 1600 +/-50 RPM
IGNITION TIMING: PERMANENTLY FACTORY SET
IDLE MIXTURE: EFI CONTROLLED
VALVE CLEARANCE: HYDRAULIC TAPPET, SELF-ADJUSTING
SPARK PLUG: NGK CPR8E9-9 SPARK PLUG GAP: 0.032" (0.8 mm)
FUEL: UNLEADED GASOLINE ONLY; 92 PUMP OCTANE OR HIGHER
OIL: 20W-40

INFORMATION SUR LE CONTRÔLE DES ÉMISSIONS DES VÉHICULES

Victory
MOTORCYCLES
U.S.A.

VICTORY MOTORCYCLE DIVISION, Polaris Industries Inc.
2100 HWY 55
HAMEL, MN, U.S.A. 55340-9800

CYLINDRÉE DU MOTEUR: 1507 cm³
FAMILLE DE MOTEUR: 4VMC001.5V92
DISPOSITIFS ANTIPOLLUTION: INJECTION SÉQUENTIELLE DE CARBURANT (SFI)
SPÉCIFICATIONS DE MISE AU POINT DU MOTEUR:
RÉGIME AU RALENTI: 1600 ± 50 tr/mn
CALAGE À L'ALLUMAGE: RÉGLE À L'USINE DE FAÇON PERMANENTE
MÉLANGE: MÉLANGE / RÉGLAGE À L'USINE ÉLECTRONIQUE DE CARBURANT (EFI)
JEU DE SOUPAPES: POUSOIR HYDRAULIQUE, À RÉGLAGE AUTOMATIQUE
BOUGIES: NGK CPR8E9-9 ÉCARTEMENT DES ÉLECTRODES DE BOUCIE: 0,8 mm (0,032 po)
CARBURANT: ESSENCE SANS PLOMB SEULEMENT; INDICE D'OCTANE À LA POMPE DE 92 OU PLUS
HUILE: 20W-40
CE VÉHICULE EST CONFORME AUX DISPOSITIONS RÉGLEMENTAIRES DE L'EPA (ÉTATS-UNIS) QUI S'APPLIQUENT AUX MOTOCYCLETTES NEUVES D'ANNÉE-MOÈDE 2004. 7171187

THIS VEHICLE CONFORMS TO USE EPA REGULATIONS APPLICABLE TO 2004 MODEL YEAR NEW MOTORCYCLES. 7171187

(Canada Models)

Victory
MOTORCYCLES
U.S.A. PATENT NOTICE

Mfd. by Victory Motorcycle Division, Polaris Industries Inc., under one or more of the following patents:
Other patents pending, U.S.
Patents:
D, 397, 976 D, 409, 551
D, 398, 065 D, 416, 831
D, 407, 169 D, 436, 561

Victory
MOTORCYCLES
U.S.A. AVIS SUR LES BREVETS

Fabriqué par Victory Motorcycle Division, Polaris Industries Inc. (Division motocyclettes de Victory), en vertu de l'un ou plusieurs des brevets suivants: Autres brevets en instance. Brevets américains.
D, 397, 976 D, 409, 551
D, 398, 065 D, 416, 831
D, 407, 169 D, 436, 561 7079796


Location I (PATENT NOTICE)
(LH Rear of subframe down tube)

COMPONENT IDENTIFICATION

Use the information on the following pages to identify and locate the major components of the VICTORY KINGPIN motorcycle, including the vehicle and engine identification numbers, model number and ignition key number.

Handlebar Components


1. Clutch Cable
2. Indicator Lamps
3. Front Brake Fluid Reservoir
4. Right Handlebar Switch
5. Right Mirror
6. Throttle Control Grip
7. Throttle Cables
8. Fuel Cap
9. Left Mirror
10. Fast Idle Lever
11. Left Handlebar Switch
12. Clutch Lever



COMPONENT IDENTIFICATION

Components


1. Front Fork
2. Front Turn Signal
3. Headlamp
4. Speedometer
5. Air Filter
6. Spark Plug (2)
7. Ignition Switch
8. Left Side Cover
9. Battery (under side cover)
10. Taillight
11. Rear Turn Signal
12. Rear Axle Adjuster (1 each side)
13. Rear Brake Caliper
14. Passenger's Foot Rest
15. Evaporative Canister - California Models
16. Oil Filter
17. Oil Drain Plug (on bottom of crankcase)
18. Sidestand
19. Operator's Foot Rest
20. Gear Shift Lever
21. Oil Cooler
22. Front Brake Caliper



COMPONENT IDENTIFICATION

Components


1. Passenger's Seat
2. Seat Strap
3. Operator's Seat
4. Rear Shock Absorber
(access through RH side cover)
5. Side Cover
6. Engine Oil Fill Cap/Dipstick
7. Front Brake Lever
8. Front Turn Signal
9. Horn
10. Front Fork
11. Rear Brake Pedal
12. Operator's Foot Rest
13. Rear Brake Fluid Reservoir
14. Drive Sprocket (under cover)
15. Fuses (under side cover)
16. Passenger Foot Rest
17. Drive Belt (under guard)
18. Exhaust Muffler (2)



COMPONENT IDENTIFICATION

Vehicle Identification Number

The vehicle identification number (VIN) is stamped into the front of the steering head and also appears on the certification label. You will need the vehicle identification number to title, register, license or insure the motorcycle, or to order replacement parts.



COMPONENT IDENTIFICATION

Engine Identification Number

The engine identification number is a combination of the engine model and serial numbers. The engine identification number is located on top of the left crankcase behind the rear cylinder.

The engine serial number is stamped into the rear of the crankcase just to the right of the oil filter. You may need the engine identification number to title, register, license or insure the motorcycle, or to order replacement parts.

Ignition Key Number

The ignition key identification number is stamped into the shaft of each key.

With the ignition key number and proof of ownership, an authorized VICTORY dealer can assist you in obtaining a replacement key.



Notice

For easy reference, record all vehicle numbers in the space provided on page 156.

INSTRUMENTS, FEATURES AND CONTROLS

Ignition Key

The ignition key operates the ignition switch and parking lights.

Ignition Switch

The ignition switch energizes the ignition, the lighting system, and all electrical switches and buttons.

Off Position

In the OFF position, all electrical circuits are inactive and the ignition key can be removed. Turn the ignition switch to the OFF position and remove the ignition key when leaving the motorcycle unattended.

On Position


In the ON position, all electrical circuits are energized and the ignition key cannot be removed. The headlamp, taillight, and instrument lights illuminate. With the engine stop/run switch set to the RUN position (see page 42) you can start the engine. You can also activate the emergency flashers, turn signals and all other electrical features.

Caution

Before starting the engine, read the instructions for starting the engine beginning on page 64.

Park Position (P)

In the PARK position, the taillight, indicator lights, and license plate light illuminate, the emergency flashers can be activated, and the ignition key can be removed. You must push the ignition key into the switch while selecting the Park position.



- 1. Off
- 2. On
- 3. P (Park)

INSTRUMENTS, FEATURES AND CONTROLS

Instrument Cluster

The instrument cluster includes the speedometer and the tachometer (if a tachometer is equipped as an accessory).

1. Speedometer
2. Odometer / Trip Odometer
3. Odometer-Trip Odometer Toggle / Trip Odometer Reset

Speedometer (1)

The speedometer reports current motorcycle speed in miles per hour (or kilometers per hour, Canada).

Odometer (2)


The odometer display shows total miles traveled in the window on the lower portion of the speedometer.

Trip Odometer (2)

A trip odometer is included on the speedometer. The trip odometer shows total miles traveled since the trip odometer was reset. You can use the trip odometer to calculate your miles per gallon and estimate the number of miles you can travel on a tank of fuel.

To toggle the display between Odometer and TRIP Odometer, the ignition switch must be in the ON position. Press the reset button (3). The display changes to “TRIP”.


To reset the trip odometer, the ignition switch must be in the ON position with the display in trip odometer mode. Press and hold the reset button (3) until the TRIP odometer display resets to zero.



INSTRUMENTS, FEATURES AND CONTROLS

Tachometer (Accessory)

An accessory tachometer (1) is available through your VICTORY dealer. The tachometer reports current engine speed in revolutions per minute (RPM). A red line on the gauge indicates maximum safe engine RPM.



WARNING

Do not operate the engine over 5600 RPM. Excessive RPM could cause engine damage or failure that could result in you losing control of the motorcycle.


INSTRUMENTS, FEATURES AND CONTROLS

Indicator Lights

Neutral Indicator (1)


N The neutral indicator illuminates when the transmission is in neutral, and the ignition key is ON.

Headlamp High Beam Indicator (2)

 The headlamp high beam indicator illuminates when the headlamp switch is set to high beam (see page 40).

Check Engine Indicator (3)

ENG The check engine indicator will illuminate any time the ignition switch is in the ON position and the engine control module sensors report abnormal sensor or engine operation. The check engine indicator will continue to illuminate as long as the fault condition exists. It also illuminates momentarily when the ignition switch is in the ON position and the engine is not running. This demonstrates that the indicator is functioning properly.



Caution

If the check engine indicator illuminates while the engine is running, a serious engine problem may exist. Contact an authorized VICTORY dealer as soon as possible.

INSTRUMENTS, FEATURES AND CONTROLS

Low Oil Pressure Indicator (4)



The low oil pressure indicator illuminates when engine oil pressure drops below safe operating pressure. If this indicator illuminates while the engine is running, turn the engine off immediately and check the oil level. Add oil if necessary. If the oil level is correct and the indicator remains illuminated after the engine is restarted, turn the engine off immediately.

The low oil pressure indicator also illuminates when the ignition switch is in the ON position and the engine is not running. This demonstrates that the indicator is functioning properly.

Turn Signal Indicator (5)




The turn signal indicator flashes when the left, right, or both turn signals are active.

If a turn signal bulb has failed, or if there is a short circuit in the turn signal system, the turn signal indicator flashes at more than twice the normal rate.

Low Fuel Indicator (6)



The low fuel indicator illuminates when approximately .4-.6 gallons (1.5-2.3 liters) of fuel remains in the tank.




INSTRUMENTS, FEATURES AND CONTROLS


Left Handlebar Controls


Fast Idle Lever (1)

The fast idle lever increases the engine idle speed when starting a cold engine (see page 64). To engage the fast idle lever, move the lever toward the rear of the motorcycle until the lever stops.

Headlamp High/Low Beam Switch (2)

 The headlamp high/low beam switch toggles the headlamp between high beam, low beam, and momentary passing beam. To activate the high beam, press the upper portion of the switch; to activate the low beam, press the lower portion of the switch. To activate the momentary passing beam, press and hold the lower portion of the switch.





1. Fast Idle Lever
2. Headlamp High/Low Beam Switch
3. Turn Signal Switch
4. Horn Button


INSTRUMENTS, FEATURES AND CONTROLS

Left Handlebar Controls

Turn Signal Switch (3)

↔ The turn signal switch activates and cancels the turn signals. To activate the left turn signals, push the switch to the left; to activate the right turn signals, push the switch to the right. To cancel the turn signals, push the switch in toward the housing when in the centered position.

Horn Button (4)

 To sound the horn, press the horn button.

Clutch Lever (5)

To disengage the clutch, pull the clutch lever toward the handlebar. To engage the clutch, gradually release the clutch lever. For smooth clutch operation, pull the lever quickly and release it gradually.

Notice The motorcycle is equipped with a clutch interlock switch that prevents the engine from starting when the transmission is in gear and the clutch is engaged (see page 64).



INSTRUMENTS, FEATURES AND CONTROLS

Right Handlebar Controls

Engine Stop/Run Switch (1)



The engine stop/run switch completes or interrupts the ignition, starter, and fuel pump circuits. To complete the circuits, allowing the engine to start and run, press the lower portion of the engine stop/run switch (RUN position). To interrupt the circuits, press the upper portion of the switch (STOP position). The engine should not start or run when the switch is in the STOP position.




Use the engine stop/run switch to turn the engine off under either normal or emergency conditions.

Emergency Flasher Switch (2)



The emergency flasher switch activates and cancels the emergency flashers. When the emergency flashers are active, all of the turn signals flash. To activate the emergency flashers, slide the switch to the left (to the triangle). To cancel the flashers, slide the switch to the right (to the dot).




1. Engine Stop/Run Switch
2. Emergency Flasher Switch
3. Starter Button
4. Throttle Control Grip

INSTRUMENTS, FEATURES AND CONTROLS

Right Handlebar Controls

Starter Button (3)

 The starter button works only when the engine stop/run switch is in the RUN position and the transmission is in neutral or the clutch is disengaged. To engage the engine starter motor, press the right side of the starter button.

For complete engine starting procedures, see Starting the Engine, page 64.

Throttle Control Grip (4)

The throttle control grip controls the engine speed. To increase engine speed, twist the throttle control grip toward you; to decrease engine speed, twist the grip away from you. When you release the grip, it returns to the idle speed position.

Front Brake Lever


The front brake lever is located on the far side of the right handlebar grip. To apply the front brake, pull the front brake lever toward the handlebar. For braking procedures in various riding conditions, see Braking, page 70.

INSTRUMENTS, FEATURES AND CONTROLS

Gear Shift Pedal (1)

The gear shift pedal is located on the left side of the motorcycle. To shift to a lower gear, press down on the toe shift pedal. To shift to a higher gear, lift up on the toe shift pedal.


For proper gear shifting procedure, see *Shifting Gears*, page 66.



Rear Brake Pedal (2)

The rear brake pedal is on the right side of the motorcycle. To engage the rear brake, press down on the rear brake pedal.

For braking procedures in various riding conditions, see *Braking*, page 70.




INSTRUMENTS, FEATURES AND CONTROLS

Fuel Cap

The fuel cap must be opened and closed with the ignition key. Lift the key slot cover (1) on the cap and insert key. Turn clockwise while pushing down lightly to release latch and open the cap. To close the fuel cap, turn key clockwise and press down on the cap. Turn key counterclockwise while maintaining pressure on the cap. Remove key and close the key slot cover.

For fueling procedure, see Fueling and Fill Height, page 63.



INSTRUMENTS, FEATURES AND CONTROLS

Side Covers

Your motorcycle is equipped with two removable side covers. Remove the left side cover to access the battery. Remove the right side cover to access the fuses and the rear brake fluid reservoir.

To remove either side cover, pull the lower corners of the side cover out slightly until lower tab is disengaged. Pull evenly on upper left and right side to disengage the two top tabs. Remove cover from the motorcycle. Be sure rubber grommets are in place before reversing the above procedure to install the side covers.

Sidestand

The sidestand is located on the left side of the motorcycle.

WARNING

Correctly retract the sidestand before operating the motorcycle. An improperly retracted sidestand could come into contact with the ground and cause loss of control.

To extend the sidestand, swing it out from the end until it is fully extended. Lean the motorcycle toward the sidestand until the sidestand firmly supports the motorcycle.

To retract the sidestand, lean the motorcycle away from the sidestand until the motorcycle is fully upright. Swing the sidestand back into its fully retracted position.

PRE-OPERATION CHECK

To keep your VICTORY motorcycle in good operating condition, always perform the checks described in this section before each ride. This is especially important before making a long trip or when removing the motorcycle from storage. You must be familiar with the VICTORY motorcycle instruments and controls to make these checks. You can find additional service information in the maintenance section of this manual, in the *VICTORY Service Manual* (P/N 9918961) or from an authorized VICTORY dealer.

During the pre-operation check you might use products that are potentially hazardous, such as oil or brake fluid. When using any of these products, follow the instructions and warnings on the product packaging.

WARNING

Failure to perform these checks before operating the motorcycle may result in serious injury or damage. Adjust components designed for normal wear adjustment, and repair or replace worn or damaged components as needed.

PRE-OPERATION CHECK

Check Electrical Equipment

To perform a pre-operation check on the electrical equipment, set the ignition switch to the ON position. Set the ignition switch to the OFF position after completing the electrical equipment portion of the pre-operation check.

Indicator Lights

The low oil pressure indicator should illuminate until the engine is started. If the transmission is in neutral, the neutral indicator should remain illuminated.

Headlamp

Check the headlamp to see that it is on. Set the headlamp switch to the high beam position. The headlamp brightness should increase and the headlamp high beam indicator light should illuminate.

Taillight / Brake Light

With the ignition switch in the ON position, the taillight and the license plate light should illuminate. Apply slight pressure to the front brake lever; taillight brightness should increase. Apply slight pressure to the rear brake pedal; taillight brightness should increase.

PRE-OPERATION CHECK

Check Electrical Equipment

Turn Signals

Move the turn signal switch to the left. The front and rear left turn signals and the turn signal indicator light on the panel should flash. Push the switch button IN to cancel the turn signal. The turn signals and turn signal indicator should stop flashing. Repeat the procedure for the right turn signals.

Emergency Flashers

Slide the emergency flasher switch to the left. All four turn signals and the turn signal indicator light on the panel should flash. Slide the switch to the right. The turn signals and turn signal indicator should stop flashing.

Horn

Press the horn button. The horn should sound loudly.

Engine Stop/Run Switch

Be sure the engine stop/run switch stops the engine, or prevents the engine from starting when set to the STOP position.



Notice If you regularly use this switch to shut off the engine, you're already checking its operation each time you use the motorcycle.

PRE-OPERATION CHECK

Check Engine Oil Level

A dipstick attached to the oil fill cap registers the engine oil level. We recommend the use of only VICTORY brand Semi-Synthetic 20W-40 Motor Oil or equivalent.

1. With the transmission in neutral, start and run the engine for several minutes.
2. Shut the engine off and wait for 3-5 minutes.
3. Straddle the motorcycle on level ground and bring it to a vertical position. Remove the oil fill cap/dipstick (1) and wipe the dipstick clean. Reinstall the dipstick and turn the cap clockwise until it seats.
4. Remove the dipstick again and read the oil level.
5. If necessary, add or remove oil to bring the level into the area on the dipstick above the ADD mark and below the FULL mark. Repeat step 1 and step 2 each time you adjust the oil level.



1. Oil Fill Cap/Dipstick
2. ADD Mark
3. FULL Mark

! WARNING

Do not operate the motorcycle with the oil level above the FULL mark or below the ADD mark. Operating the engine with too much or too little oil can cause serious engine damage or engine seizure, resulting in loss of control.

PRE-OPERATION CHECK

Check Fuel Components

Fuel Level


1. Straddle the motorcycle on level ground and bring it to a vertical position.
2. Turn the ignition switch to the ON position and watch the fuel indicator light on the panel. **NOTE:** The light will stay on if less than .4-.6 gallons (1.51-2.27 liters) remains in the tank after starting the engine.
3. Check the fuel level.
4. Estimate your next fuel stop and plan accordingly to avoid running out of fuel.

Fuel Hose, Rail and Connections

Inspect the fuel hoses for cracks or damage. Inspect the hose connection at the fuel tank and at the fuel rail for dampness or stains from leaking or dried fuel.

Evaporative Emission Control System (California models)

Visually inspect all evaporative emission control system hoses and connections. Make sure all connections are tight. Inspect the evaporative canister to make sure it has not been damaged. The canister is located on the left side of the motorcycle behind the side stand.



PRE-OPERATION CHECK

Check Tires

Tire Pressure

Normal riding warms the tires and increases the tire air pressure. For an accurate reading, check the tire pressure before you ride. Adjust tire pressure as required for the total weight of your intended load. Refer to the tire pressure table on page 114.

Tire Condition

Inspect the tire sidewalls, road contact surface, and tread base for cuts, punctures, and cracking. Replace damaged tires immediately (see the *VICTORY Service Manual* PN 9918961 or an authorized VICTORY dealer).

Tire Tread Depth

Raised areas at the base of the tread, known as wear bars, act as easily visible tread depth indicators. See page 115.


When the road contact surface has worn to the top of the wear bars, replace the tire.

PRE-OPERATION CHECK

Check Brakes


Front Brake Lever Movement

Squeeze the front brake lever toward the handlebar and release it. It should move freely and smoothly and should return to its rest position quickly when released. You should feel a firm resistance in the lever within the first 3/4-inch (19 mm) of lever travel.



Front Brake Fluid Level

1. To check the front brake fluid level, rest the motorcycle on the sidestand and on level ground. Turn the handlebars until the front brake fluid reservoir is level.
2. View the brake fluid through the sight glass. The fluid should be clear and at a level in or above the sight glass. Add brake fluid if necessary (see page 107).



1. Front Brake Fluid Reservoir Sight Glass


PRE-OPERATION CHECK

Check Brakes

Rear Brake Pedal Freeplay and Movement


Rear brake pedal freeplay, the amount of brake pedal movement from the rest position to the point of contacting the master cylinder, should be .080 - .160 inch (2-4 mm). Adjust pedal freeplay as necessary (see page 109).

Press and release the rear brake pedal. It should move freely and smoothly and should return to its rest position quickly when you release it. You should feel a firm resistance in the pedal within the first 3/8 inch (8 mm) of pedal travel.



Check Rear Brake Fluid Level

1. To check the rear brake fluid level, remove the right side cover. Straddle the motorcycle and bring it to a vertical position.
2. View the brake fluid through the reservoir. The fluid should be clear and at a level between MIN and MAX. Add brake fluid if necessary (see page 110).



1. Rear Brake Fluid Reservoir
2. MIN Fluid Level
3. MAX Fluid Level

PRE-OPERATION CHECK


Check Brakes

Check Hoses and Connections

Inspect all brake hoses and connections for dampness or stains from leaking or dried fluid. Tighten any leaking connections and replace components as necessary.

Check Brake Pads

Look at the front brake caliper pads at (1), and at rear rear brake caliper pads at (2). You should see at least 1/16 inch (1.6 mm) of friction material on each of the brake pads (see page 112). If in doubt, measure remaining friction material. Replace brake pads having less than the specified amount of friction material at their thinnest point.




1. Front Brake Pad Friction Material

2. Rear Brake Pad Friction Material

Check Throttle Control Grip and Cables

1. Rotate the throttle control grip. It should rotate smoothly from its rest position to its completely open position and back again. It should return to its rest position quickly when released.
2. Throttle freeplay, the amount of throttle control grip movement from the rest position to the point of cable resistance, should be 1/8-1/4 inch (3-6 mm).
3. Adjust throttle cable freeplay if necessary (see page 101).




PRE-OPERATION CHECK

Check Clutch

1. Squeeze the clutch lever toward the handlebar and release it. It should move freely and smoothly and should return to its rest position quickly when released.
2. Clutch freeplay, the amount of clutch lever movement from the rest position to the point of cable resistance, should be between 0.010-0.030 inch (.25-.75 mm). Measure the thickness of the gap between the clutch lever and the lever housing.
3. Adjust clutch lever freeplay if necessary (see page 104).


NOTE: The starter interlock switch is dependent on the clutch lever freeplay being set correctly to ensure activation of the clutch safety switch.



1. Clutch Lever
2. Lever Housing
3. Gap

Check Fast Idle Lever

1. Move the fast idle lever. It should move smoothly from its rest position to its completely open position and back again.
2. Fast idle lever freeplay, the amount of lever movement from the rest position to the point of cable resistance, should be 1/8-1/4 in. (3-6 mm).
3. Adjust fast idle lever freeplay if necessary (see page 100).




PRE-OPERATION CHECK

Check Front Suspension

- 1. To check the front suspension, straddle the motorcycle and bring it to a vertical position.
- 2. Apply the front brake and push down hard on the handlebars several times. The front suspension should operate smoothly and quietly.
- 3. Place the motorcycle on the sidestand and inspect the front forks. Make sure there is no fork oil present on the fork tube or around the fork seal.

Check Steering

Straddle the motorcycle and bring it to a vertical position. Turn the handlebars from stop to stop. The action should be smooth but not loose or interfered with by wires, hoses or control cables.



1. Front Fork Tube
2. Fork Seal

PRE-OPERATION CHECK

Check Rear Suspension

Proper rear suspension adjustment is essential for a safe and comfortable ride. Check the rear shock absorber movement and preload to ensure that the motorcycle has the correct amount of suspension travel and ground clearance (see page 92).

WARNING

Inadequate ground clearance could allow components to come into contact with the ground, causing loss of control.

Check Drive Belt

The drive belt should fit tightly. Check drive belt tension (see pages 86-87).

Replace the drive belt if it is cracked or has broken teeth or frayed edges (consult your *VICTORY Service Manual* or an authorized VICTORY dealer).

PRE-OPERATION CHECK


Check Sidestand

Straddle the motorcycle and bring it to a vertical position. Move the sidestand to its stored (up) position, then to its fully extended (down) position and back again. It should move smoothly and quietly. When the sidestand is in its stored position, the sidestand return spring should hold the sidestand tightly against the motorcycle.

Check the condition of the sidestand rubber pad, and make sure it's firmly attached to the sidestand.

Check Fasteners

Visually inspect the entire motorcycle chassis and engine for loose, damaged or missing fasteners. Tighten loose fasteners to the proper torque (see the specifications section of this manual or see the *VICTORY Service Manual*). Immediately replace stripped, damaged or broken fasteners with genuine VICTORY fasteners of equal size and strength immediately.



- 1. Sidestand
- 2. Rubber Pad

OPERATION

The operation section describes how to operate your VICTORY motorcycle for best performance and longevity. Important areas covered include:

- Engine Break-in Period
- Fueling and Fill Height
- Starting the Engine
- Shifting Gears
- Accelerating
- Braking
- Stopping the Engine
- Parking

For safe operation and riding, see the safety section beginning on page 6.

Engine Break-in Period

During the first 500 miles (800 kilometers), critical engine parts require special wear-in procedures so they seat and mate properly. Read, understand and use the following rules for operating the motorcycle during the first 500 miles (800 kilometers) to ensure your engine's long-term performance and durability.

Caution

Do not put unnecessary load on the engine during the first 500 miles (800 kilometers). Avoid prolonged full throttle operation or any condition that creates excessive engine heat.

OPERATION

Engine Break-in Period

0-90 miles (0-145 kilometers)

- Do not operate the motorcycle for extended periods of time at throttle positions above 1/3 throttle. Vary the engine speed of the motorcycle. Do not operate the motorcycle for extended periods of time at any one set throttle position.

90-300 miles (145-483 kilometers)

- Do not operate the motorcycle for extended periods of time at throttle positions above 1/2 throttle. Vary the engine speed of the motorcycle. Do not operate the motorcycle for extended periods of time at any one set throttle position.

300-500 miles (483-800 kilometers)

- Do not operate the motorcycle for extended periods of time at throttle positions above 3/4 throttle.

At 500 miles (800 kilometers)

- Perform initial maintenance as described in the Maintenance section of the *Owner's Manual*. This maintenance is one of the most important services your motorcycle requires and should be performed by an authorized VICTORY dealer. Initial maintenance includes servicing all adjustments, tightening all fasteners, and changing engine oil. Performing this maintenance at the required mileage point helps the engine maintain top performance for its entire service life.

Caution

If engine trouble should occur during the engine break-in period, consult the maintenance section of the *Owner's Manual*, the *VICTORY Service Manual*, or an authorized VICTORY dealer immediately.

Engine Break-in Period

Fueling and Fill Height

Fuel the motorcycle with the sidestand down and on level ground. Use only the recommended fuel (see Fuel Specifications on page 151). Fill the fuel tank to a level just below the bottom of the fuel filler insert.

WARNING

- **Do not allow gasoline to come into contact with a hot engine or exhaust system. This could cause a fire. Immediately wipe, or rinse with water, gasoline spilled on any part of the motorcycle or the surrounding area.**
 - **Do not fill the fuel tank above the fuel filler insert. Overfilling the fuel tank may cause fuel to overflow when it expands.**
 - **Fuel may leak from an improperly seated fuel cap. Be sure the fuel cap properly seated and locked before starting the engine.**
-

Caution

Fuel can damage painted surfaces and plastic parts. Wipe spilled fuel immediately from the motorcycle using a clean, dry, soft cloth.

Fuel System Priming Procedure (Out of Gas)

Notice If the motorcycle has run completely out of fuel, cycle the fuel pump 4-5 times to prime the system before starting the engine. To cycle the fuel pump, set the ignition switch to the ON position and toggle the engine stop/run switch from the STOP position to the RUN position 4-5 times. Wait a few seconds in the RUN position between cycles.

OPERATION

Engine Break-in Period

Starting the Engine

The VICTORY motorcycle has a starter interlock system. The engine can be started only when the transmission is in neutral or when the transmission is in gear and the clutch is disengaged.

Follow these steps to start the motorcycle:

1. Perform the Pre-Operation Check as outlined beginning on page 47. If you're carrying cargo, inspect the cargo restraints for tightness.
2. Insert the ignition key into the ignition switch and turn the switch to the ON position (see page 35).
3. Mount the motorcycle and bring it to an upright position. Engage the front brake and place the sidestand in the stored (up) position. If the neutral indicator is not illuminated, shift the transmission to neutral (see Shifting Gears, page 66).
4. If the engine is cold (has not been run in a few hours) move the fast idle lever toward the rear of the motorcycle until the lever stops.
5. Set the engine stop/run switch to the RUN position. You should hear the fuel pump momentarily as it pressurizes the fuel system.

Engine Break-in Period

Starting the Engine

6. Leaving the throttle closed, press and hold the starter button until the engine starts. If the engine does not start within a few seconds after you press the starter button, release the button and wait several seconds. Then press and hold the starter button again. Hold the starter button for as short a time as possible to minimize battery drain, and do not push the starter button for more than 10 seconds at any one time.
NOTE: If either the check engine indicator or the low oil pressure indicator does not go out after the engine starts, stop the engine. See either Check Engine Indicator, page 38, or Low Oil Pressure Indicator, page 39.
7. As soon as the engine warms enough to idle smoothly, move the fast idle lever toward the front of the motorcycle until the lever stops.

Caution

Do not rev the engine or put the transmission in gear immediately after starting the engine. Allow the engine to idle for about one minute after a cold start, or 30 seconds after a warm start to allow the oil to reach all areas requiring lubrication before the engine is put under load.

OPERATION

Shifting Gears

⚠ WARNING

The clutch must be fully disengaged (clutch lever pulled completely in toward the handlebars) before you attempt to shift gears. Forced shifting (shifting without the clutch disengaged) may damage the engine, transmission and drive train, causing loss of control of the motorcycle.

The motorcycle is equipped with a five-speed transmission. The gear pattern is shown in the illustrations at right.

TOE SHIFT PEDAL: (Top Photo) Shift to a higher gear by lifting the front of the pedal with your toe. To shift to a lower gear, depress the pedal with your toe.

HEEL / TOE SHIFT PEDAL: (Bottom Photo) Shift to a higher gear by lifting the front peg of the pedal with your toe, or depress the rear peg of the pedal with your heel. To shift to a lower gear, depress the front pedal with your toe.

Neutral position is between first and second gear. The transmission is in neutral when the motorcycle moves forward or backward freely while the clutch is engaged (clutch lever released). With the ignition switch set to the ON position, the neutral indicator illuminates when the transmission is in neutral.



Shifting Gears

1. To engage first gear, start the engine (see Starting the Engine on page 64).
2. With the engine at idle speed, engage the front brake (squeeze the brake lever) and disengage the clutch (squeeze the clutch lever).
3. Push the front peg of the shift pedal down with your toe until you feel it stop in first gear.
4. Disengage the front brake (release the brake lever).
5. Simultaneously moving both the clutch lever and the throttle control grip with a smooth, gentle motion, gradually engage the clutch (release the clutch lever) and open the throttle (roll the throttle control grip toward you).
6. As the clutch begins to engage, the motorcycle begins to move forward.
7. To shift to the next higher gear, accelerate smoothly and easily to the recommended shift point (see Recommended Shift Points on page 68).
8. With a quick motion, simultaneously close the throttle completely and disengage the clutch.
9. Raise the shift pedal with your toe, (or if your motorcycle is equipped with a heel/toe shift pedal, you can also press down on the rear peg of the pedal with your heel), until you feel it stop at the next gear.
10. Simultaneously moving both the clutch lever and the throttle with a smooth, gentle motion, gradually release the clutch lever and open the throttle.

NOTE: Within the recommended speed ranges (see Recommended Shift Points on page 68), you can downshift (shift to a lower gear) to slow the motorcycle or to increase the available power. You may want to downshift when climbing a hill or passing. Downshifting also helps to decrease your speed when combined with closing the throttle.

11. To shift to a lower gear, simultaneously pull in the clutch lever and close the throttle. Shift into the next lower gear by depressing the shift pedal with your toe. Simultaneously release the clutch lever and open the throttle.

OPERATION

Shifting Gears

WARNING

- Downshifting at a speed in excess of the recommended downshift point may severely damage the transmission or cause the rear wheel to lose traction. It could also result in engine damage from running at excessive rpm. Reduce speed before downshifting and do not downshift at a speed above that in the table of recommended shift points.
 - Downshifting abruptly on wet, rough, loose or slippery surfaces can cause the motorcycle to skid. When downshifting while passing over such surfaces, release the clutch lever very gradually.
 - Downshifting in a curve may cause the rear wheel to lose traction. Downshift before entering a curve.
-

Recommended Shift Points

The following table shows the appropriate speed at which to shift up or down to each gear.

Upshift (Acceleration) Gear Change	Upshift Speed		Downshift (Deceleration) Gear Change	Downshift Speed
1st to 2nd	15 mph (24 km/h)		5th to 4th	35 mph (56 km/h)
2nd to 3rd	25 mph (40 km/h)		4th to 3rd	25 mph (40 km/h)
3rd to 4th	35 mph (56 km/h)		3rd to 2nd	15 mph (24 km/h)
4th to 5th	45 mph (72 km/h)		2nd to 1st	10 mph (16 km/h)

Accelerating

To accelerate, open the throttle (roll the throttle control grip toward you). For even acceleration, open the throttle with a smooth, continuous motion. When you reach the recommended speed for upshifting, shift up one gear according to the instructions in Shifting Gears, page 66. The more quickly you open the throttle, the more quickly the motorcycle accelerates.

WARNING

- **Abrupt acceleration can cause your body to shift suddenly toward the rear of the motorcycle.**
 - **Accelerating abruptly on wet, rough, loose, or slippery surfaces may cause the rear wheel to lose traction. When accelerating on such surfaces, whether you are at a stop or already in motion, open the throttle gradually.**
-

OPERATION

Braking

To slow the motorcycle with the brakes, close the throttle and apply the front and rear brakes evenly. As the motorcycle slows, either disengage the clutch or downshift each time your speed reaches a downshift point. Applying slightly more front brake than rear brake generally gives you the best braking performance. Do not apply the brakes so forcefully or quickly that either wheel stops rotating. Leave sufficient distance so you can apply the brakes gradually if you need to stop.

WARNING

- **Do not apply either brake so strongly that the wheel stops rotating. This may cause loss of control.**
 - **Braking hard on wet, rough, loose, or slippery surfaces can cause the motorcycle to skid, and you could lose control of the motorcycle. Apply the brakes lightly on such surfaces.**
 - **Braking while in a curve can cause loss of control. Bring the motorcycle to the upright position before applying the brakes, and avoid applying the brakes in a corner if at all possible.**
-

Stopping the Engine

Before stopping the engine, bring the motorcycle to a complete stop either in neutral or with the clutch disengaged. Once the motorcycle is at a complete stop, if it is not already in neutral, shift into neutral. To stop the engine, set the engine stop/run switch to the STOP position, turn the ignition switch to the OFF position, and remove the ignition key.

WARNING

- **Stopping the engine while the motorcycle is in motion and the transmission is engaged may damage the engine and the transmission or cause the rear wheel to lose traction. In either case, you may lose control.**
 - **If the motorcycle is in motion and the engine stops on its own, guide the motorcycle to a safe location off the road and away from traffic.**
-

OPERATION

Parking the Motorcycle

When parking the motorcycle, choose a flat, firm surface. Bring the motorcycle to a complete stop and, with the transmission in neutral, stop the engine. Fully extend the sidestand, turn the handlebars to the left, and lean the motorcycle to the left until the sidestand firmly supports the motorcycle. Take the key with you.

If you must park on a slope, point the motorcycle toward the top of the slope. Put the transmission in gear and park the motorcycle so that it is stable when it rests on the sidestand.

If you must park on a soft surface, use a sidestand plate under the foot of the sidestand to provide a firm surface. The sidestand footrest must be strong enough and large enough to support the motorcycle's weight without sinking into the parking surface. Many motorcyclists carry a sidestand plate.

Parking the Motorcycle

Caution

Asphalt pavement can become soft in hot weather. The sidestand can sink into soft asphalt until the motorcycle falls over. When parking on asphalt in hot weather, use a sidestand footrest under the foot of the sidestand to prevent the sidestand from sinking into the asphalt.

WARNING

A hot engine or hot exhaust pipes can be hazardous. The engine and exhaust pipes are hot for some time after the engine is stopped. Touching the engine or exhaust pipes while hot can cause serious burns. Allowing flammable materials to contact a hot engine or exhaust pipes may cause a fire. Park the motorcycle where people will not touch the engine or exhaust pipes and where it is not near flammable materials.

MAINTENANCE

This section includes information for maintaining your VICTORY motorcycle. It includes recommended periodic maintenance intervals, which outlines the regular service required to keep your motorcycle in the best operating condition. Regular service increases motorcycle durability, safety, and dependability, and it provides greater riding pleasure. Also refer to the safety-related maintenance information beginning on page 21.

Before you begin any maintenance procedure, read the instructions for the entire procedure in this section of the *Owner's Manual*. Choose a flat, firm surface for servicing the motorcycle. Make sure you have the time, tools, and expertise to complete a procedure properly.

During maintenance you might use products that are potentially hazardous; such as oil or brake fluid. When using any of these products, follow the instructions and warnings on the product packaging.

For information on major repairs, see the *VICTORY Service Manual*. Major repairs typically require the technical skills and specially designed tools available from your authorized VICTORY dealer.

Your VICTORY dealer has the equipment and training required to properly perform emission system maintenance and repairs.

Initial Maintenance

Perform the initial maintenance after you've ridden your new motorcycle 500 miles (800 kilometers). This maintenance is one of the most important services your motorcycle requires and should be performed by an authorized VICTORY dealer. Initial maintenance includes servicing all adjustments, tightening all fasteners, and changing engine oil. Performing this maintenance at the required mileage point helps the engine maintain top performance for its entire service life.

Periodic Maintenance Intervals

Use the following table to determine how often you should perform maintenance on various components. For additional information on maintenance operations for each component listed in the table, refer to the instructions in this section.

Caution

If you regularly ride your motorcycle at high or low speed for extended periods of time, or in dusty or other adverse conditions, perform the required maintenance more frequently to help keep your motorcycle in safe operating condition.

Notice Use the space provided at the back of this manual to record information about maintenance performed on your motorcycle.

MAINTENANCE

Periodic Maintenance Interval Table

Component (see operation codes below)	See Page	ODOMETER READING in MILES (KILOMETERS)																				
		500 (800)	2,500 (4,000)	5000 (8,000)	7,500 (12,000)	10,000 (16,000)	12,500 (20,000)	15,000 (24,000)	17,500 (28,000)	20,000 (32,000)	22,500 (36,000)	25,000 (40,000)	27,500 (44,000)	30,000 (48,000)	32,500 (52,000)	35,000 (56,000)	37,500 (60,000)	40,000 (64,000)	42,500 (68,000)	45,000 (72,000)	47,500 (76,000)	50,000 (80,000)
Engine Oil*	81	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Engine Oil Filter*	81	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Air Filter	84	I	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R
Drive Sprocket/Nut	85							I						I						I		
Drive Belt	86	I	I	I	I	I	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	I
Rear Wheel Alignment	89	I		I		I		I		I		I		I		I		I		I		I
Rear Shock Absorber	92	I		I		I		I		I		I		I		I		I		I		R
Steering Bearings	97	I	I	I	I	I	I	L	I	I	I	I	I	L	I	I	I	I	I	L	I	I
Swing Arm and Rear Axle	95	I		I		I		I		I		I		I		I		I		I		I
Front Fork Oil**	96	I		I		I		R		I		I		R		I		I		R		I
Front Forks/Front Axle	97	I		I		I		I		I		I		I		I		I		I		I
Fuel System	98	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I

Operation Codes:

I-Inspect (tighten, clean, adjust, correct or replace if necessary)

R-Replace/Rebuild

*Replace at specified interval or annually

L-Lubricate with proper lubricant

P-Perform

**Replace at specified interval or every 2 years

MAINTENANCE

Periodic Maintenance Interval Table (continued)

Component (see operation codes below)	See Page	ODOMETER READING in MILES (KILOMETERS)																				
		500 (800)	2,500 (4,000)	5000 (8,000)	7,500 (12,000)	10,000 (16,000)	12,500 (20,000)	15,000 (24,000)	17,500 (28,000)	20,000 (32,000)	22,500 (36,000)	25,000 (40,000)	27,500 (44,000)	30,000 (48,000)	32,500 (52,000)	35,000 (56,000)	37,500 (60,000)	40,000 (64,000)	42,500 (68,000)	45,000 (72,000)	47,500 (76,000)	50,000 (80,000)
Crankcase Ventilation System	98	I		I		I		I		I		I		I		I		I		I		I
Evaporative Emission Control System (California Only)	98	I		I		I		I		I		I		I		I		I		I		I
Fuel Filter	99										R											R
Fast Idle Lever	100	I		I		L		I		L		I		L		I		L		I		L
Throttle	101	I	I	I	I	L	I	I	I	L	I	I	I	L	I	I	I	L	I	I	I	L
Clutch Lever	102	I		I		L		I		L		I		L		I		L		I		L
Control Cables	105	I		I		L		I		L		I		L		I		L		I		L
Front Brake Lever	106	I		I		L		I		L		I		L		I		L		I		L
Rear Brake Pedal	108	I		I		L		I		L		I		L		I		L		I		L
Brake Fluid**	107 110	I	I	I	I	I	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	I
Brake Hoses and Lines	111	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	R

Operation Codes:
 I-Inspect (tighten, clean, adjust, correct or replace if necessary) R-Replace/Rebuild *Replace at specified interval or annually
 L-Lubricate with proper lubricant P-Perform **Replace at specified interval or every 2 years

MAINTENANCE

Periodic Maintenance Interval Table (continued)

Component (see operation codes below)	See Page	ODOMETER READING in MILES (KILOMETERS)																				
		500 (800)	2,500 (4,000)	5000 (8,000)	7,500 (12,000)	10,000 (16,000)	12,500 (20,000)	15,000 (24,000)	17,500 (28,000)	20,000 (32,000)	22,500 (36,000)	25,000 (40,000)	27,500 (44,000)	30,000 (48,000)	32,500 (52,000)	35,000 (56,000)	37,500 (60,000)	40,000 (64,000)	42,500 (68,000)	45,000 (72,000)	47,500 (76,000)	50,000 (80,000)
Brake Pads	112	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Gear Shift Pedal	113	I		I		L		I		L		I		L		I		L		I		L
Tires	114	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Wheel Spokes	116	I		I		I		I		I		I		I		I		I		I		I
Spark Plugs	118	I		I		I		I		I		I		R		I		I		I		I
Engine Compression	117	I				I				I				I				I				I
Exhaust System	117	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Battery	121	I		I		I		I		I		I		I		I		I		I		I
Headlamp	128	I				I				I				I				I				I
Sidestand	126	I		I		L		I		L		I		L		I		L		I		L
Fasteners	129	I		I		I		I		I		I		I		I		I		I		I
Road Test	129	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P
<p>Operation Codes: I-Inspect (tighten, clean, adjust, correct or replace if necessary) R-Replace/Rebuild *Replace at specified interval or annually L-Lubricate with proper lubricant P-Perform **Replace at specified interval or every 2 years</p>																						

MAINTENANCE

MAINTENANCE RECORD			
MAINTENANCE PERFORMED	MILES / KM	NOTES	PERFORMED BY:

MAINTENANCE

MAINTENANCE RECORD			
MAINTENANCE PERFORMED	MILES / KM	NOTES	PERFORMED BY:

Engine Oil


Change Engine Oil and Oil Filter (Oil Change Kit PN 2873551)

⚠ WARNING

A hot engine or hot exhaust pipes can be hazardous. The engine and exhaust pipes are hot for some time after the engine is stopped. Touching the engine or exhaust pipes while hot can cause serious burns. Allowing flammable materials to contact a hot engine or exhaust pipes may cause a fire. Park the motorcycle where people will not touch the engine or exhaust pipes and where it is not near flammable materials.

1. Start and run the engine until it reaches normal operating temperature. Stop the engine.
2. Securely support the motorcycle on the sidestand.
3. Place an oil drain pan under the drain plug (1) and oil filter (2).
4. Remove the drain plug and seal using the universal tool provided under the left side cover (see page 122) or a good quality 6mm Allen socket, allowing the oil to drain into the pan.
5. Use an oil filter wrench to loosen the filter slowly. Allow oil in the filter to drain before removing the filter.
6. Use a new seal and reinstall the drain plug.

Torque: 20 ft-lbs (27 Nm)
7. Clean any residue or debris from oil filter mounting plate and threads.



MAINTENANCE

Engine Oil

Change Engine Oil and Oil Filter

8. Make sure the new oil filter gasket is properly seated in the oil filter, and apply a thin film of clean engine oil to the gasket. Screw the new filter on until the gasket contacts the filter mounting plate. Tighten the filter *by hand* an additional 3/4 turn.
9. Fill the crankcase through the oil fill cap with 6 quarts (5.7 liters) of oil. We recommend the use of only VICTORY Brand Semi-Synthetic 20W-40 Motor Oil or equivalent.
10. Reinstall the oil fill cap and then start and run the engine until it reaches normal operating temperature.

Caution

After an oil change, the low oil pressure indicator remains illuminated longer than usual before going out. Revving the engine while the low oil pressure indicator is illuminated can damage the engine.

11. Stop the engine and make sure there are no leaks around the drain plug and oil filter. Check the oil level and adjust if needed.



Notice

Recycle used oil and oil filter in accordance with local regulations.

Engine Oil

Check Engine Oil Level

1. With the transmission in neutral, start and run the engine for several minutes.
2. Shut the engine off and wait for 3-5 minutes.
3. With the engine at normal operating temperature, straddle the motorcycle on level ground and bring it to a vertical position. Remove the oil fill cap and wipe the dipstick clean. Reinstall the dipstick and turn the cap clockwise until it seats.
4. Remove the dipstick again and note the oil level.
5. If necessary, add or remove oil to bring the level into the area on the dipstick, above the ADD mark and below the FULL mark (see page 50). Repeat steps 1-2 each time you adjust the oil level.



1. Oil Fill Cap/Dipstick
2. ADD Mark
3. FULL Mark

WARNING

Do not operate the motorcycle with the oil level above the FULL mark or below the ADD mark. Operating the engine with too much or too little oil can cause serious engine damage or engine seizure, resulting in loss of control of the motorcycle.

MAINTENANCE

Inspect Air Filter

The standard VICTORY air filter element is a dry paper design and does not require the use of air filter oil.


Notice Inspect the air filter often if riding in unusually wet or dusty conditions.

1. Remove the air filter access cover and air filter element using the universal tool provided under the left side cover (see page 122).
2. To remove debris from the element, use low-pressure air and blow from the rear forward.

WARNING

Wear eye and face protection when using pressurized air.

3. Apply a small amount of lubricant to the edge of the air filter element frame and reinstall the element and access cover. Do not over-tighten the access cover screws.



1. Air Filter Access Cover
2. Air Filter Element

Inspect Drive Sprocket and Sprocket Nut

1. Remove the drive sprocket cover.

Notice On some models you may have to remove portions of the exhaust system to access all of the drive sprocket cover screws (see the *VICTORY Service Manual* or an authorized VICTORY dealer).

2. Inspect drive sprocket and sprocket nut for wear or damage. Make sure the sprocket nut is tight.

3. If the sprocket nut is loose, remove the sprocket nut retainer screws and the retainer.

4. Remove the sprocket nut.

5. Inspect the seal sleeve/sprocket spacer. The machined surface should be smooth and free from burrs or galling.

6. Clean the output shaft threads and the sprocket nut threads.

7. Apply a few drops of LOCTITE Thread Locker #262 or equivalent to the output shaft threads.

8. Apply the rear brake and tighten the drive sprocket nut.


Torque: 125 ft-lbs (170 Nm)

9. Install the nut retainer and the retainer screws. Rotate the retainer plate clockwise and hold it against the nut when retainer screws are tightened.

Torque: 85 in-lbs (10 Nm)

Notice The nut retainer can be installed in many positions and on either side. If you cannot align the mounting holes, tighten the sprocket nut slightly and install the nut retainer.

10. Check rear wheel alignment (page 89) and drive belt tension (page 86).



MAINTENANCE

Drive Belt

Check Drive Belt Condition


Replace the drive belt if it is cracked or has broken teeth or frayed edges. No matter its condition, the drive belt should be replaced at periodic intervals (see the *VICTORY Service Manual* or an authorized VICTORY dealer). DO NOT attempt to check belt tension if the belt has been exposed to rain or washing within a 24 hour period or if the belt is hot from riding. Allow the belt to cool down to ambient temperature before measuring belt tension.

Check Drive Belt Tension

This procedure involves using the belt tension gauge, part no. PV-43532, which is designed specifically for measuring drive belt tension.

Before beginning this procedure:

- Make sure the drive belt is dry and at room temperature.
 - Make sure the rear suspension is properly adjusted (see Adjust Rear Shock Absorber, page 92).
1. Place the transmission in Neutral and lift the rear wheel off the ground with an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.



1. Belt Tension Gauge
2. Small O-Ring
3. Base
4. Plunger


! WARNING

Care should be taken to be sure the motorcycle will not tip or fall while elevated. Severe personal injury or death may occur if the motorcycle tips or falls.

Drive Belt

Check Drive Belt Tension

2. Position the small O-ring on the belt tension gauge directly over the 10 lbs. mark on the plunger as shown.
3. Place a tape measure or rule next to the drive belt as shown.
4. Place the base of the tension gauge bracket squarely against the lower strand of the drive belt halfway between the front and rear drive sprockets. Use the tape measure or ruler and record the position of the base of the tension gauge bracket. This position represents *zero force*.
5. Push the plunger upward until the small O-ring touches the tension gauge body. Make sure the tension gauge is seated squarely against the drive belt, and record the position of the base of the tension gauge bracket. This position represents *10 lbs. force*.
6. Calculate the difference between the *zero force* position and the *10 lbs. force* position you recorded. The difference should be:
 $23/64$ inch \pm $1/64$ inch (9.0 mm \pm .5mm)
7. Adjust belt tension as necessary. See page 88.



MAINTENANCE

Drive Belt

Adjust Drive Belt Tension

WARNING


Care should be taken to be sure the motorcycle will not tip or fall while elevated. Severe personal injury or death may occur if the motorcycle tips or falls.

Notice Before adjusting drive belt tension, inspect wheel alignment. (See Align Rear Wheel, page 89).

1. Loosen the rear axle nut (A).
2. Insert the universal tool (see page 122) through the access hole in the back of the swingarm and turn both left and right axle adjusters (B) an equal amount (if wheel is in alignment) or turn each adjuster in or out as required to align wheel and achieve proper tension (see Check Drive Belt Tension, page 86).
3. When alignment and belt tension is correct, tighten the rear axle nut.

Torque: 65 ft-lbs (88 Nm)

4. Recheck drive belt tension.
5. Pump rear brake pedal several times to reset brake pad distance.



Rear Wheel Alignment


! WARNING

A skewed rear axle can damage the drive belt, causing it to fail and loss of control of the motorcycle.

! WARNING

Care should be taken to be sure the motorcycle will not tip or fall while elevated. Severe personal injury or death may occur if the motorcycle tips or falls.

1. Bring the motorcycle to a vertical position.
2. Place the transmission in Neutral and lift the rear wheel off the ground with an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.
3. The axle washers (1) and the swingarm (2) are stamped with marks that are used as a reference to ensure proper wheel alignment. Inspect the position of the axle washer alignment marks on each side in relation to the mark on the swingarm. The marks should be in the same position on both sides.
4. To adjust the rear wheel alignment, loosen the rear axle nut (3) about 1 1/2 turns.



MAINTENANCE

Rear Wheel

Alignment (cont.)

NOTE: Turn the axle adjusters about 1/16 of a turn at a time and monitor wheel alignment as you proceed.

5. Insert the universal tool (4) through the access hole in the back of the swingarm and turn the axle adjuster bolt IN (clockwise) to draw the axle back or OUT (counterclockwise) to push the axle forward.
6. Recheck rear wheel alignment as outlined after each adjustment. Readjust if necessary, until the marks on both axle washers are in the same position in relation to swingarm marks and the drive belt tension is correct (see Check Drive Belt Tension, page 86).
7. When wheel is aligned according to the marks and drive belt tension is correct, tighten the axle nut.

Torque: 65 ft-lbs (88 Nm)



Rear Wheel Alignment (cont.)

8. Recheck drive belt tension and alignment to be sure it is correct after tightening the axle.
9. If alignment is incorrect, repeat steps 4-7.
10. Pump rear brake pedal several times to reset brake pad distance.
11. Carefully lower the motorcycle and safely support it on the sidestand.

WARNING

Care should be taken to be sure the motorcycle will not tip or fall while elevated. Severe personal injury or death may occur if the motorcycle tips or falls.

MAINTENANCE

Rear Suspension


Adjust Rear Shock Absorber

This procedure involves using the shock absorber preload wrench, a special spanner tool available from your dealer (P/N PV-46993). The tool is designed specifically for adjusting shock spring preload on your motorcycle.

Notice The distance measured while the motorcycle is elevated will not change, and needs only be measured once. After the measurement and the locations from where the measurement is taken is recorded (steps 1-4), you will only need to perform steps 5-8 to correctly adjust the rear shock absorber spring.

Have an assistant help you complete the following procedure.

1. Elevate the rear of the motorcycle until the rear wheel is about 1 inch (2.5 cm) off of the ground. Use an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.
2. Measure the distance from the center of the rear axle to the bottom of the rear fender directly above the axle.
3. Record the measurement and the locations from where the measurement is taken in the space provided.
4. Remove the motorcycle lift apparatus and return the motorcycle to the ground.



1. Center of Rear Axle
2. Bottom of Rear Fender

Measurement (step 2) _____


Upper Location (step 2) _____

Lower Location (step 2) _____

Rear Suspension

Adjust Rear Shock Absorber

5. Load the motorcycle with all the things you intend to carry (cargo and accessories). With the motorcycle in an upright position, sit on the operator's seat with your riding gear on, and if you plan on carrying a passenger, have that person sit on the passenger seat with riding gear on.
6. Have your assistant bounce the rear suspension a few times by pushing down on the rear fender slowly and releasing. Make sure the suspension moves freely without binding.
7. Without moving the motorcycle, have your assistant measure the distance from the center of the rear axle to the bottom of the rear fender directly above the axle. This measurement must be taken from the same locations recorded in step 2.
8. Subtract the second measurement (step 7) from the first measurement (recorded in step 2). The difference is called "sag" and should be 1 to 1 3/8 inch (25 to 35 mm).
9. To adjust the pre-load (change sag dimension):
 - A. Remove the right side cover.
 - B. Remove the fuse box from right panel by lifting upward on the tab at the forward end while pulling the fuse box forward.
 - C. Remove 3 bolts holding panel to chassis.
 - D. Press on plastic dart that holds the electrical harness to separate the harness from the panel.
 - E. Carefully pull back panel and electrical harness to access the spring adjuster nut.




MAINTENANCE

Rear Suspension

Adjust Rear Shock Absorber (Cont.)

10. The uppermost spanner nut on the shock is the locknut (1). The spanner nut closest to the spring is the adjuster nut (2). Loosen the locknut by turning it counterclockwise (as viewed from the top of shock absorber).
11. Adjust shock absorber preload by rotating adjuster nut clockwise (as viewed from the top of shock absorber) to **DECREASE** the sag measurement, and counterclockwise to **INCREASE** the sag measurement.
12. Re-check sag dimension after adjustment.
13. Tighten lock nut securely against adjuster nut when adjustment is complete.
14. Reinstall electrical harness to right panel and slide fusebox into position.
15. Tighten the 3 bolts that secure the panel to the chassis to 85 inch lbs. (10 Nm).
16. Re-install the right side cover.



1. Preload Adjustment Collar Locknut
2. Preload Adjustment Collar
3. Reduce Sag Measurement
4. Increase Sag Measurement

Rear Suspension

Inspect Swing Arm and Rear Axle

1. Remove the swing arm pivot covers and tighten the swingarm pivot nut (located on the right side) while holding the left side of the pivot axle.

Torque: 85 ft-lbs (115 Nm)

2. Reinstall the pivot nut covers.
3. Sit in the operator's seat and slowly bounce the rear suspension a few times. Make sure the suspension moves freely without binding.
4. Elevate the rear of the motorcycle until the rear wheel is off of the ground. Use an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.
5. Grasp the rear tire and attempt to move the rear wheel side-to-side.
NOTE: If there is movement at the rear axle, inspect the wheel bearings and rear axle (see the *VICTORY Service Manual* or an authorized VICTORY dealer).
If there is movement at the front of the swing arm, check the swing arm pivot nut torque. If movement is still present, inspect the swing arm pivot bushings (see the *VICTORY Service Manual* or an authorized VICTORY dealer).
6. With the transmission in neutral, slowly rotate the rear wheel. If the wheel does not rotate smoothly, inspect the wheel bearings, rear axle, belt adjustment, and wheels alignment (see the *VICTORY Service Manual* or an authorized VICTORY dealer).

MAINTENANCE

Front Suspension and Steering

WARNING


Care should be taken to be sure the motorcycle will not tip or fall while elevated. Severe personal injury or death may occur if the motorcycle tips or falls.

Check Front Forks

1. To check the front suspension, straddle the motorcycle and bring it to a vertical position.
2. Apply the front brake and push down hard on the handlebars several times. The front suspension should operate smoothly and quietly.
3. Place the motorcycle on the sidestand and inspect the front forks. Make sure there is no fork oil present on the fork tube (1) or around the fork seal (2).
4. Clean the fork tubes as required to remove bugs, tar, or buildup which may cause seal wear or leakage.

Replace Front Fork Oil

Front fork oil condition and level is associated with front suspension performance and internal component wear. For fork oil replacement procedures and special tools required, see the *VICTORY Service Manual* or contact an authorized VICTORY dealer.



Front Suspension and Steering

WARNING

Care should be taken to be sure the motorcycle will not tip or fall while elevated. Severe personal injury or death may occur if the motorcycle tips or falls.

Inspect Steering and Front Axle

1. Elevate the front of the motorcycle until the front wheel is off of the ground. Use an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.
2. Turn the handlebars from stop to stop. The action should be smooth but not loose or interfered with by wires, hoses, or control cables.
3. Point the front wheel straight ahead. Grasp the front forks near the front axle and attempt to move the front wheel front-to-back. **NOTE:** If there is front-to-back movement at the steering head, the steering head bearings should be inspected, lubricated, and adjusted (see the *VICTORY Service Manual* or an authorized VICTORY dealer).

Notice The steering head bearings require periodic lubrication even if there is no front-to-back movement at the steering head when checked (see the *VICTORY Service Manual* or an authorized VICTORY dealer).

4. Turn the handlebars all the way to the right or left. Grasp the front tire and attempt to move the front wheel side-to-side. **NOTE:** If there is movement at the front axle, inspect the wheel bearings and front axle (see the *VICTORY Service Manual* or an authorized VICTORY dealer).
5. Slowly rotate the front wheel. If the wheel does not rotate smoothly, inspect the wheel bearings, front axle, and brakes (see the *VICTORY Service Manual* or an authorized VICTORY dealer).

MAINTENANCE

Fuel System

Check Fuel Hose, Rail, and Connections

Inspect the fuel hoses for cracks or damage. Inspect the hose connection at the fuel pump and at the fuel rail for dampness or stains from leaking or dried fuel.

Check Crankcase Ventilation Hose and Connections


Remove the operators seat and fuel tank. Inspect the crankcase ventilation hose for cracks or damage. Inspect the hose connection at the air cleaner and at the crankcase for dampness or stains from leaking.

Evaporative Emission Control System (California models only)

Visually inspect all evaporative emission control system hoses and connections. Make sure all connections are tight. Also, inspect the evaporative canister to make sure it has not been damaged.

Fuel Tank Removal / Installation

1. To remove the fuel tank, remove the operator's seat.
2. Remove the front and rear fuel tank mounting screws.
3. Unplug the fuel level sensor and fuel pump wire harness.
4. With engine and exhaust cool, remove fuel rail bleed valve cap (1). Wrap a clean rag around the valve and relieve the fuel line pressure by depressing the center of the bleed valve.



Fuel System

Caution

Fuel can damage painted surfaces and plastic parts. Wipe spilled fuel immediately from the motorcycle using a clean, dry, soft cloth.


5. Loosen hose clamp and disconnect the fuel line (2).
6. Disconnect the tank vent line and carefully remove fuel tank.
7. To reinstall the fuel tank, reverse the removal steps, routing fuel line to the right of breather hose.
8. Reinstall the fuel tank mounting screws.

Torque: 35 ft-lbs (47.5 Nm)

9. Reinstall the seat.

Replace Fuel Filter

The fuel filter is attached to the electric fuel pump located inside the fuel tank. Fuel filter condition is associated with engine performance and fuel economy. For fuel filter replacement procedures and special tools required, see the *VICTORY Service Manual* or contact an authorized VICTORY dealer.



MAINTENANCE



Fast Idle Lever and Cable

1. Move the fast idle lever. It should move smoothly from its rest position to its completely open position and back again. Measure fast idle lever free-play (A), which is the amount of lever movement from the rest position to the point of cable resistance.

Specification: 3-6mm, 1/8-1/4 in.

Fast Idle Lever Freeplay

2. If adjustment is necessary, remove seat (page 120) and fuel tank (page 98).
3. Loosen the fast idle cable adjuster jam nut (B).
4. Turn the cable adjuster in or out until the fast idle lever freeplay is 1/8-1/4 inch (3-6 mm).
5. Tighten the adjuster jam nut securely and reinstall the fuel tank and operator's seat.
6. Start the engine and let it idle with transmission in NEUTRAL.
7. Turn the handlebars from full right to full left. If engine RPM increases when bars are turned, re-check throttle cable and fast idle cable adjustments, cable condition, and routing. If problem persists contact your VICTORY dealer.




Throttle

Check Throttle Control Grip and Cable

1. Rotate the throttle control grip. It should rotate smoothly from its rest position to its completely open position and back again. It should return to its rest position quickly when released.
2. Throttle freeplay - the amount of throttle control grip movement from the rest position to the point of cable resistance - should be 1/8-1/4 inch (3-6 mm).
3. Adjust throttle freeplay if necessary.

Adjust Throttle Freeplay

1. Slide the rubber covers off both cable adjusters, and loosen both adjuster jam nuts.
2. Turn both cable adjusters into the cable as far as possible.
3. Turn the cable adjuster on the throttle opening cable out until the throttle freeplay is 1/8-1/4 in. (3-6 mm).
4. Hold the throttle control grip at the fully closed position and turn the cable adjuster on the throttle closing cable out until resistance is felt.
5. Tighten the adjuster jam nuts on both cables, and reinstall both rubber covers.
6. Verify that the throttle grip moves smoothly throughout the full range of rotation and returns freely when released.




MAINTENANCE

Clutch

Check Clutch Lever and Cable

1. Squeeze the clutch lever toward the handlebar and release it. It should move freely and smoothly and should return to its rest position quickly when released.
2. Clutch freeplay - the amount of clutch lever movement from the rest position to the point of cable resistance - should be between 0.010-0.030 inch (.25-.75 mm). Measure the gap between the clutch lever and the lever housing.
3. Adjust clutch freeplay if necessary (see page 104).



1. Clutch Lever
2. Lever Housing
3. Gap

Clutch

Lubricate Clutch Lever

1. Remove the right side cover.
2. Slide the rubber cover off the cable adjuster, and loosen the adjuster jam nut.
3. Turn the cable adjuster all the way in.
4. Remove clutch lever pivot nut and screw.
5. Disconnect the clutch cable from the clutch lever.
6. Remove any old grease and dirt from the clutch lever and lever housing.
7. Lubricate the clutch lever and lever pivot screw with VICTORY All Purpose Grease or equivalent.
8. Reconnect the clutch cable and reinstall the clutch lever, lever pivot screw, and nut.

Torque: 40 in-lbs (5 Nm)



9. Adjust clutch freeplay.

MAINTENANCE

Clutch

Adjust Clutch Freeplay

1. Remove the right side cover.
2. Hold cable (1) and loosen the adjuster jam nut (2).
Turn cable adjuster (3) while holding cable.
3. Turn the cable adjuster in or out until the clutch freeplay (A) is .010-.030 inch (.25-.75 mm).
4. Tighten the adjuster jam nut (2) securely while holding cable (1).
5. Reinstall right side cover.
6. Verify that the safety switch activates so the motorcycle cannot be started in gear with clutch lever released.



Lubricate Control Cables

The following cables used on the motorcycle require periodic lubrication for smooth operation and maximum service life:

- Throttle Cables
- Clutch Cable
- Fast Idle Lever Cable

1. Loosen the adjuster of the cable to be lubricated, and disconnect one end of the cable.
2. Lubricate the cable and the inside of the cable housing with VICTORY Cable Lube (PN 2872861) or a commercially available cable lubricant.
3. Lubricate the cable end with VICTORY All Purpose Grease or equivalent.
4. Reconnect the cable and adjust as necessary.

Clutch Cable Adjustment: See page 104.

Throttle Cable Adjustment: See page 101.

Fast Idle Cable Adjustment: See page 100.

MAINTENANCE

Brakes


Check Front Brake Lever Movement

Squeeze the front brake lever toward the handlebar and release it. It should move freely and smoothly and should return to its rest position quickly when released. You should feel a firm resistance in the lever within the first 3/4-inch (19 mm) of lever travel.

If the brake lever travels too far before beginning to engage the brake, see the *VICTORY Service Manual*, or contact an authorized VICTORY dealer for service.

Lubricate Front Brake Lever

1. Remove right side mirror, brake lever pivot nut and pin.
2. Remove any old grease and dirt from the brake lever and lever housing.
3. Lubricate the brake lever and lever pivot pin with VICTORY All Purpose Grease or equivalent.
4. Reinstall the brake lever, lever pivot pin, and nut.
5. Verify proper installation of push rod (1) with large radius oriented toward lever, and small radius toward master cylinder.
6. Torque the lever pivot pin first, using a 4mm hex socket.
7. Hold the pivot pin stationary and torque nut using a 10mm socket.
Torque (Pivot pin and nut): 5 ft-lbs (52 inch-pounds) (6 Nm)
8. Check front brake lever movement.



Brakes

Check Front Brake Fluid Level


1. To check the front brake fluid level, rest the motorcycle on the sidestand and on level ground. Turn the handlebars until the front brake fluid reservoir is level.
2. View the brake fluid through the sight glass (1). The fluid should be clear and at a level in or above the sight glass. Add brake fluid if necessary.

Add Front Brake Fluid

1. Straddle the motorcycle and bring it to a vertical position. Turn the handlebars until the reservoir is horizontal.
2. Wipe the area around the reservoir cover with a clean cloth.
3. Wipe the brake fluid container with a clean cloth.
4. Remove the reservoir cover and gasket.

Caution

Brake fluid attacks painted surfaces and plastic parts. Always clean spilled brake fluid immediately with plenty of water and a mild detergent.



MAINTENANCE

Brakes

WARNING

- **Do not operate the front brake while its reservoir cover is removed. Fluid could overflow from the reservoir and cause air to enter the fluid system. Air in the brake fluid system could cause the brakes to malfunction.**
 - **Use only DOT 4 brake fluid from a sealed, clean container. Using the wrong brake fluid, or allowing contaminants into the brake fluid system, can damage the system seals, resulting in the brakes malfunctioning.**
-

5. Reinstall the reservoir gasket and cover.
6. Carefully add enough brake fluid to bring the level just above the sight glass.

Check Rear Brake Pedal Freeplay and Movement

Rear brake pedal freeplay - the amount of brake pedal movement from the rest position to the point of contacting the master cylinder - should be .080-.160 inch (2-4 mm). Adjust pedal freeplay as necessary (see page 109).



Press and release the rear brake pedal. It should move freely and smoothly and should return to its rest position quickly when you release it. You should feel a firm resistance in the pedal within the first 3/8 inch (8 mm) of pedal travel.

If the brake pedal travels too far before beginning to engage the brake, see the *VICTORY Service Manual*, or contact an authorized VICTORY dealer for service.

Brakes

Adjust Rear Brake Pedal Freeplay

- 1 If the pedal freeplay is outside of specification, push the dust boot (1) back to expose top of actuator rod (2).
- 2 Hold the actuator rod and loosen the lock nut (3).
- 3 Rotate the actuator rod as necessary to achieve the correct brake pedal freeplay.
- 4 Tighten the lock nut securely and verify that the rear wheel rotates freely without drag or binding through the full freeplay range of the pedal. If drag is evident, repeat the adjustment procedure or consult an authorized Victory dealer.



MAINTENANCE

Brakes

Check Rear Brake Fluid Level


1. To check the rear brake fluid level, remove the right side cover. Straddle the motorcycle and bring it to a vertical position.
2. View the brake fluid through the reservoir. The fluid should be clear and at a level between MIN and MAX. Add brake fluid if necessary.

Add Rear Brake Fluid

1. Bring the motorcycle to a vertical position with an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.
2. Remove the right side cover.
3. Wipe the area around the reservoir cover with a clean cloth.
4. Wipe the brake fluid container with a clean cloth.
5. Remove the reservoir cover and gasket.

Caution

Brake fluid attacks painted surfaces and plastic parts. Always clean spilled brake fluid immediately with plenty of water and a mild detergent.



1. Rear Brake Fluid Reservoir
2. MIN Fluid Level
3. MAX Fluid Level

Brakes

WARNING

- **Do not operate the rear brake while its reservoir cover is removed. Fluid could overflow from the reservoir and cause air to enter the fluid system. Air in the brake fluid system could cause the brakes to malfunction.**
 - **Use only DOT 4 brake fluid from a sealed, clean container. Using the wrong brake fluid, or allowing contaminants into the brake fluid system, can damage the system seals, resulting in the brakes malfunctioning.**
-

6. Carefully add enough brake fluid to bring the level between MIN and MAX.
7. Reinstall the reservoir gasket and cover.
8. Reinstall the side cover.

Inspect Brake Hoses and Lines

1. Carefully inspect brake hoses and brake lines for abrasion or damage. Inspect all connections for leaks. Be sure all guide clamps and straps are in place to secure the hoses and lines. Refer to the VICTORY SERVICE MANUAL (PN 9918961) for line routing and guide/strap locations.
2. If abrasion, damage, or leakage is found contact your Victory dealer immediately for service.

MAINTENANCE

Brakes

Check Brake Pads

Look at the front brake caliper pads at (1), and at rear rear brake caliper pads at (2). You should see at least 1/16 inch (1.6 mm) of friction material on each of the brake pads. If in doubt, measure remaining friction material. Replace brake pads having less than the specified amount of friction material at their thinnest point.


If the brake pads require replacement, see the *VICTORY Service Manual* or an authorized VICTORY dealer for assistance.

Check Brake Disc


Visually inspect the brake disc for nicks, scratches, cracks, or other damage. Inspect the thickness of each brake disc in at least four points around the disc. Minimum thickness is stamped on the inner hub of the disc. If the front or rear disc has worn to the minimum thickness at the thinnest point, or if the disc is damaged, contact your VICTORY dealer for replacement.

Check Brake Hoses and Connections



Inspect all brake hoses and connections for dampness or stains from leaking or dried fluid. Tighten any leaking connections and replace components as necessary.



1. Front Brake Pad Friction Material



2. Rear Brake Pad Friction Material



Replace pads if worn to less than 1/16" (1.6mm)


Gear Shift Pedal

Adjust Gear Shift Pedal Height


1. Loosen the gear shift linkage rod locknuts.
2. Turn the linkage rod in or out as necessary.
3. Tighten the linkage rod locknuts.
4. Check the gear shift pedal height.

Caution

Do not remove and reposition the shift arm on the shift shaft to adjust gear shift pedal height. A $90^\circ \pm 5^\circ$ angle between the shift arm and the linkage rod must be maintained to ensure correct shift linkage operation.



1. Shift Linkage Rod Lock Nut
2. Shift Linkage Rod



MAINTENANCE

Tires

Check Tire Pressure

Normal riding warms the tires and increases the tire air pressure. For an accurate reading, check the tire pressure before you ride. Adjust tire pressure as required for the total weight of your intended load.

Tire Pressure Table

KINGPIN		
	Up to 200 lbs (91 kg) load	200-465 lbs (91-211 kg) load
FRONT: Dunlop 491 Elite II 130/70-B18 63H	32 psi (222 kpa)	36 psi (248 kpa)
REAR: Dunlop D417 180/55-B18 74V	36 psi (248 kpa)	41 psi (283 kpa)

Tires


Check Tire Condition

Inspect the tire sidewalls, road contact surface, and tread base for cuts, punctures, and cracking. Replace damaged tires immediately (see your *VICTORY Service Manual* or an authorized VICTORY dealer).

Check Tread Depth

Raised areas at the base of the tread, known as wear bars; act as easily visible tread depth indicators. When the road contact surface has worn to the top of the wear bars, replace the tire.

For more precise measurement, use a depth gauge or an accurate ruler to measure the depth of the center tire tread. Replace the tire if the tread depth is less than 1/16 inch (1.6 mm).



1. Tread Depth Gauge

MAINTENANCE

Check Wheel Spokes

If your motorcycle is equipped with spokes, inspect both wheels for loose, bent, broken or missing spokes. To identify loose spokes, grasp each spoke and try to move it side to side or up and down. All spokes should be equally tight and have the same amount of flex. Tighten loose spokes or replace bent, broken or missing spokes (see an authorized VICTORY dealer).



! WARNING

Spokes adjusted or replaced improperly could distort the wheel, make the motorcycle difficult to handle, and cause loss of control.

Check Engine Compression

An accurate periodic engine compression check documents engine wear and condition. For engine compression check procedures and special tools required, see the *VICTORY Service Manual* or contact an authorized VICTORY dealer.

Check Exhaust System

Check the exhaust system for stains from leaking exhaust gasses. Replace exhaust gaskets if necessary (see the *VICTORY Service Manual* or an authorized VICTORY dealer). Check all exhaust system fasteners.

1. Tighten exhaust header flange nuts.

Torque: 12 ft-lbs (16 Nm)

2. Tighten muffler clamps.


Torque: 45 ft-lbs (61 Nm)

3. Tighten muffler mounting screws.

Torque: 11 ft-lbs (15 Nm)

4. Tighten muffler bracket screws.

Torque: 11 ft-lbs (15 Nm)



1. Header Flange Nut
2. Muffler Clamp

3. Muffler Mounting Screw
4. Muffler Bracket Screw

MAINTENANCE


Check or Replace Spark Plugs

The spark plugs must be removed from the engine to inspect them. Spark plugs with bright white deposits, sooty black deposits, or with damaged insulators or electrodes can indicate engine problems. If these conditions exist, or if the condition of one plug is markedly different from the other, see the *VICTORY Service Manual* or an authorized VICTORY dealer for assistance.

1. Make sure the engine is at room temperature.
2. Disconnect the spark plug wire by pulling upward on the spark plug boot (Page 31).
3. To prevent any debris from entering the engine through the spark plug hole, use pressurized air to blow clean the area around each spark plug before removing it.

WARNING

Wear eye and face protection when using pressurized air.



1. Insulator
 2. Electrode Tip
 3. Electrode Bridge
- Type: NGK CPR6EA-9**

MAINTENANCE

Check or Replace Spark Plugs

4. Remove the spark plug from the cylinder head with a 5/8 inch spark plug socket.

Both spark plugs should have the same light or medium tan color deposits on the insulator around the electrode tip. The spark plug electrode tip and bridge should have sharp, square edges.

If spark plugs are in good condition and are not due for replacement, you can clean them with a non-metallic stiff bristle brush, set the gap and reinstall them.

Replace spark plugs (NGK CPR6EA-9 or equivalent) at the recommended intervals. Always replace spark plugs in pairs.


5. Set the electrode gap with a spark plug gauge.

Gap: 0.032 inch (0.8 mm)

6. Clean the mating surface on the cylinder head and install the spark plug with a spark plug socket.

Torque: 8 ft-lbs (11 Nm)

7. Reconnect both spark plug wires.



MAINTENANCE


Seat Removal and Installation

There are two separate seats, the operator's seat and the passenger seat. It is not necessary to remove the passenger seat for regular maintenance. The passenger seat mounting screws are located on each side of the seat under the side covers.

WARNING

Always make sure the seats are securely fastened before riding the motorcycle. A loose seat could cause a sudden shift in riding position, causing loss of control.

1. Remove the right and left side covers.
2. Remove the fuse box from the bracket (see page 27).
3. Remove the screws located on the right and left sides of the operator's seat.
4. Lift the rear of the seat and pull rearward and up to remove.
5. To reinstall the seat, place the seat in position on the frame.
6. Push down on the rear of the seat until the screw holes align.
7. Install the screws and tighten securely.
8. Reinstall the fuse box on bracket.
9. Install the left and right side covers.



Battery

WARNING

The battery contains sulfuric acid, which can cause severe burns. Do not allow sulfuric acid to contact skin, eyes, or clothing.

Antidotes:

- **External: Flush with water.**
 - **Internal: Drink large quantities of water or milk. Follow with milk of magnesia, beaten eggs, or vegetable oil. Call physician immediately.**
 - **Eyes: Flush with water for 15 minutes and get prompt medical attention.**
-

The motorcycle uses a permanently sealed, maintenance-free battery. Do not remove the battery cap strip for any reason. Keep the battery connections clean and tight at all times.

Notice If your VICTORY motorcycle will not be used for a period of 6 weeks or longer, a maintenance charger should be connected to the battery. A fused maintenance charger connection is provided beneath the left side cover. The connector is designed for use with the VICTORY maintenance charger available at your authorized VICTORY dealer.

MAINTENANCE


Battery

Battery Removal

1. Remove the left side cover and battery cover.
2. Disconnect the negative (-) battery cables (cable ends are exposed).
3. Disconnect the positive (+) cables (cable ends are covered with a red boot).

Caution

Disconnecting the positive cable first can produce an electric shock that could result in damage or injury.



4. Slide the battery out.

Universal Tool (A)

The universal tool is located in a holder under the left side cover. The universal tool can be used to service the following items:

Oil Drain Plug

Handlebar Adjustment

Belt Tension Adjusters (After loosening axle nut)

Turn Signal Bulb

Accessory Windshield Fasteners

Accessory Driver's Backrest Fasteners

Indicator Bulbs

Headlight Bulb

Accessory Saddlebag Fasteners

Air Filter

Passenger Seat (Unless the motorcycle is equipped with a touring package)

Battery

Battery Charging

WARNING

The battery may contain explosive gases.

- **Keep sparks, cigarettes, or any flame away from the battery.**
 - **Shield eyes and protect skin and clothing when handling or working near the battery.**
 - **Make sure ventilation is adequate when charging or using the battery in an enclosed space.**
 - **During charging, if the battery gets very hot to the touch, stop charging and let the battery cool down before continuing.**
-

1. Clean oxidation from the battery posts and cable connectors with a wire brush. Wash the posts and cable connectors with a solution of 1 part baking soda to 16 parts water. Rinse with clean water and wipe dry. Apply a thin film of dielectric grease to the posts and cable connectors.
2. Following the charger manufacturer's instructions, use a battery charger designed for use with 12-volt batteries. The charger should have a maximum charging rate of 1.8 amps. Charge the battery for approximately 10 hours at a rate of 1.8 amps. If you use a taper or trickle charger, it will take longer to charge the battery.
3. After charging the battery, use a voltmeter to check the condition of the battery. Allow battery to sit 1-2 hours before checking the charge. The charge should be a minimum of 12.5 volts. Repeat the charging cycle if the charge is less than the minimum. Replace the battery if it fails to reach a 12.5 volt charge after two complete charging cycles.

MAINTENANCE

Battery

Battery Installation

1. Before installing the battery, make sure it's fully charged and clean.
2. Slide the battery into position in the battery tray with positive (+) terminal to rear of motorcycle.
3. Connect the positive (+) battery cables, tighten securely and install the red boot.
4. Connect the negative (-) cables, tighten securely. Be sure cables have adequate side cover clearance.

Caution

- Connecting the negative cable first can produce an electric shock that could result in damage or injury.
 - Connecting the battery cables to the wrong terminals can severely damage the electrical system.
-

5. Reinstall the battery cover.
6. Reinstall the left side cover.

Fuses


Caution

Use only recommended amperage fuses to avoid damage to the electrical system.

1. Remove the right side cover and release the fuse box from the bracket.
2. Release the tabs on each side of the fuse box cover, and remove the cover.
3. Remove the damaged fuse from the fuse box and seat the new fuse firmly in its place. A spare 15 amp fuse is located in the fuse box.
4. Reinstall the fuse box cover with the double cutout toward the front of the motorcycle. The fuse box decal should be readable from the right side of the motorcycle.
5. Reinstall the fuse box to the bracket.

NOTE: The fuse box assembly can be removed by lifting the lever tab at the front of the fuse box and sliding the box forward to release from bracket. (See page 27).

6. Reinstall the side cover and the operator's seat.



Fuse Application	Fuse Size
Engine / ECM	15 amp
Fuel Pump	10 amp
Headlamp / Brake Lamp	15 amp
Tail Lamp, Flashers, Indicator Lamp, Horn	15 amp
Ignition / Gauges	15 amp
Spare Fuse	15 amp

MAINTENANCE

Sidestand

Straddle the motorcycle and bring it to a vertical position. Move the sidestand to its stored (up) position, then to its fully extended (down) position, and back again. It should move smoothly and quietly. When the sidestand is in its stored position, the sidestand return spring should hold the sidestand tightly against the motorcycle.


If the sidestand is bent, it should be replaced immediately.

Caution

Do not try to straighten a bent sidestand. The sidestand will be weakened, and may not be able to support the motorcycle.

Inspect Sidestand Pad

1. Check the condition of the sidestand rubber pad, and make sure it is firmly attached to the sidestand.
2. Inspect the sidestand rubber pad for wear. Replace the rubber pad if it is worn above the wear limit (see the *VICTORY Service Manual* or an authorized VICTORY dealer).



1. Sidestand
2. Rubber Pad

Sidestand

Sidestand Lubrication

1. Bring the motorcycle to a vertical position with an appropriate motorcycle lift or a block of wood or steel placed securely under the frame.
2. Move the sidestand to its stored (up) position.

WARNING

Wear face protection. The sidestand return spring is under tension and can injure your eyes and face when released.

3. Remove the sidestand pivot bolt and remove the sidestand return spring.
4. Wipe any old grease and dirt from the sidestand, frame, and pivot bolt.
5. Lubricate the sidestand and pivot bolt with VICTORY All Purpose Grease or equivalent.
6. Reinstall the sidestand spring and place the sidestand on the mounting boss, with the stand in the stored (up) position.
7. Install the pivot bolt and tighten to specified torque.
Torque: 35 ft-lbs (47 Nm)
8. Check to be sure the sidestand moves freely through its pivot range.

MAINTENANCE



Headlamp Adjustment

The headlamp should shine straight ahead of the motorcycle. The top of the headlamp High beam should be just below the center of the lamp at a distance of 25 feet (7.62 m).

1. Check and adjust the tire pressure (page 114)
2. Verify suspension sag is 25-35mm (see page 92) before adjusting headlight.
3. Straddle the motorcycle in an upright position and sit in the operator's seat.
4. Set the ignition switch to the ON position and set the headlamp to High beam. Check the headlamp for correct aim.
5. To adjust the headlamp, loosen pivot nut (1) while holding bolt (2).
6. Aim headlight and hold in position while tightening nut.

Torque: 35 ft-lbs (48 Nm)

7. Verify proper headlamp adjustment and re-adjust if necessary.



Check Fasteners

Visually inspect the entire motorcycle chassis and engine for loose, damaged, or missing fasteners. Tighten loose fasteners to the proper torque (see the Specifications section of the *Owner's Manual*, or the *VICTORY Service Manual*). Replace stripped, damaged, or broken fasteners with genuine VICTORY fasteners of equal size and strength immediately.

Road Test

Before returning the motorcycle to regular use, road test it in a safe environment. Pay special attention to the proper fit and operation of all serviced components. Make any corrections or additional adjustments as necessary to ensure safe and enjoyable vehicle performance.



WARNING

Improperly installed or adjusted components can make the motorcycle unstable or hard to handle. Improperly installed electrical components can cause engine or electrical system failure. In either case, damage or serious injury could result.

MAINTENANCE

NOTES:

CLEANING

This section explains how to properly clean the various parts of your VICTORY motorcycle to keep it in good working order and appearance.

General Cleaning

Clean your motorcycle regularly to protect it from corrosion and to keep it looking new. As you clean your motorcycle you perform a complete and thorough visual inspection that may reveal components in need of repair.

Clean the motorcycle if it is dusty or muddy, or if it has picked up foreign material such as road salt, insects, oil, tar, or tree sap. If you ride in an area with salty or polluted air, wash your motorcycle frequently. Proper cleaning requires washing and drying the motorcycle, and then applying wax, polish, and protectants to extend the service life and appearance of various components.

During cleaning you might use products that are potentially hazardous, such as polishing compounds. When using any of these products, follow the instructions and warnings on the product packaging.

Some foreign materials like insects, oil, tar, and tree sap can damage the motorcycle's fit and finish, and you should remove these materials as soon as possible. If normal washing does not remove these materials, you may need to use a special cleaner. Choose a cleaner designed for use on the type of surface you need to clean.

CLEANING

Washing and Drying the Motorcycle

Before washing the motorcycle, make sure the exhaust pipes are not hot. Cover each exhaust pipe opening with a plastic bag and attach the bag to the pipe with a strong rubber band. To prevent contamination from water, check that the spark plugs, spark plug wire caps, oil fill cap, and fuel caps are properly seated.

1. Park the motorcycle in the shade to prevent water spotting.
2. The engine cases are painted. If you choose to use a degreaser, follow the degreaser manufacturer's instructions.
3. Rinse off as much dirt and mud as possible with water running at low pressure.

Caution

- Don't use high water pressure or high-pressure sprayers such as those found at car washes. Excessive water pressure may allow water to seep in and deteriorate wheel bearings, brake caliper assemblies, brake master cylinders, electrical connectors, steering head bearings, and transmission seals.
 - Electrical components may be damaged by contact with water. Do not spray or allow water to come into contact with electrical components or connectors.
-
4. Wash the entire motorcycle using a soft cloth or sponge soaked in a solution of mild detergent and warm water, applying minimal pressure as you wash. Let the detergent do the cleaning, not the pressure you apply. Excessive washing pressure may cause dirt, sand, or other foreign materials on the motorcycle to scratch the finish. Keep the cloth or sponge clean by rinsing it frequently, and soak it in the detergent and water solution to provide plenty of soapy water for washing. A toothbrush or bottle brush can help you wash places that are difficult to reach with a cloth or a sponge.

Washing and Drying the Motorcycle

Caution

Use as little water as possible when washing near the air cleaner or the exhaust pipe openings. An excessively wet air cleaner, or water in the exhaust pipes, may cause the engine to start and run poorly. Dry these components thoroughly before using the motorcycle.

5. Clean the front fork tubes thoroughly to reduce fork seal wear and leakage.
6. If insects, oil, tar, tree sap, or other foreign material is difficult to remove by applying gentle pressure using the warm water and mild detergent mixture, you may need to use a special cleaner. Choose a cleaner designed for use on the type of surface you plan to clean.
7. Rinse the motorcycle with water running at low pressure.
8. Remove the rubber bands and plastic bags from the exhaust pipes, and wipe the motorcycle dry with a soft cloth or chamois.
9. After washing the motorcycle, start the engine and let it idle for a few minutes. Make sure the brakes are functioning properly before riding.

WARNING

Excessively wet brake pads or discs may diminish braking effectiveness. Dry these components thoroughly before using the motorcycle.

CLEANING

Waxing, Polishing and Applying Protectants

(Items Other Than Windshields and Leather Saddlebags)

After washing and drying the motorcycle, you can help extend the life and appearance of its components by waxing painted surfaces, polishing chrome surfaces, and applying a protectant to exposed rubber, vinyl, and plastic parts. Avoid cleaning-waxing compounds, as they may contain abrasives that may damage the finish of painted parts. For chrome surfaces, use either a window-cleaning solution or a polish specifically designed for chrome. Follow manufacturer's instructions for proper application and use of wax, polish, or protectants.

After washing and drying the motorcycle, to help extend the life and appearance of its components:

- Wax painted surfaces. Avoid cleaning-waxing compounds, as they may contain abrasives that may damage the finish of painted surfaces.
- Polish chrome surfaces. Use either a window-cleaning solution or a polish specifically designed for chrome.
- Apply a protectant to leather (saddlebag outer cover on Kingpin equipped with Touring Package), exposed rubber, vinyl, and plastic components.

WARNING

- **Do not use a protectant on the seats, footpegs, or handgrips that leaves a slippery coating after it dries. If these surfaces are slippery, you may have difficulty holding your position on the motorcycle while riding, which may cause loss of control.**
 - **Follow manufacturer's instructions and safety precautions on wax, polish, and protectant labels to prevent injury or damage.**
-

Windshield Care

If your motorcycle is equipped with an optional windshield:

Wash the windshield using a soft cloth or sponge soaked in a solution of mild detergent and warm water, applying minimal pressure as you wash. Let the detergent do the cleaning, not the pressure you apply. Excessive washing pressure may cause dirt, sand, or other foreign materials on the windshield to scratch it. Soak the cloth or sponge in the detergent and water solution frequently to provide plenty of soapy water for washing, and keep the cloth or sponge clean by rinsing it frequently.

- Minor scratches may be removed with a quality plastic polishing compound. Follow the manufacturer's instructions when using plastic polishing compounds.
- Insects, oil, tar, and tree sap may also damage the motorcycle's finish. If normal washing does not remove these materials, you may need to use a special cleaner. Choose a cleaner designed for use on clear plastic and follow the manufacturer's instructions when using special cleaners.

Caution

Do not use glass cleaners, water or soil repellents, petroleum or alcohol based cleaners, as these products can damage the windshield.

CLEANING

Leather Saddlebag Care

If your motorcycle is equipped with optional leather saddlebags:

Natural leather has “character.” Each piece used in the construction of these saddlebags is unique, and will settle into its own distinct form over time and miles. Mature leather is one-of-a-kind, and if properly cared for, gets better with age.

Caring for natural leather is similar to caring for your own skin. To prevent leather from becoming hard and dry, occasionally apply a leather conditioner. A good quality leather conditioner replaces the natural oils lost by repeated exposure to sun, wind and rain. Leather subject to drier climates will require more frequent conditioning.

To retain the beauty and character of your leather saddlebags, please follow these steps.

1. Vacuum or blow any loose dust or dirt from the saddlebag.
2. Use a good quality saddle soap and a sponge or soft cloth to clean the saddlebag. Always follow the manufacturer’s directions. Rinse the saddlebag with a clean wet cloth or sponge.
3. Once the leather is dry, treat it with a good quality leather conditioner. Always follow the manufacturer’s directions.
4. Allow the conditioner to dry, and wipe off any excess before using the saddlebag.

Repairing Painted Surface Damage

After cleaning the motorcycle, inspect it for damage to the painted surfaces. If you discover chips or scratches in the paint, apply genuine VICTORY touch-up paint as soon as possible to prevent corrosion.

STORAGE

If you will not operate the motorcycle for several months, such as during the winter, store the motorcycle to prevent damage to the fuel system and the battery and to protect components from corrosion or deterioration. During storage you might use products that are potentially hazardous; such as fuel stabilizer. When using any of these products, follow the instructions and warnings on the product packaging.

This section includes instructions for preparing the motorcycle for storage, maintaining it during storage and removing it from storage.

Storage Area Preparation

Choose a dry, well-ventilated storage location, inside a garage or other structure if possible. The location should have a firm, flat surface and allow enough space for the motorcycle.

To best preserve tire condition:

- The storage area should have a relatively constant and moderate temperature.
- The motorcycle should not be near a radiator or other heat source, or any type of electric motor.
- The storage surface should be free of oil and gasoline.

Clean and Protect the Motorcycle

To prepare the motorcycle for storage, begin by cleaning it as outlined beginning on page 131. Wax painted surfaces and polish chromed surfaces. Apply protectant to exposed rubber, vinyl, and plastic parts.

Caution

Do not apply rubber protectant to the tire tread surfaces.

STORAGE

Fuel Stabilizer

1. Using a mixture of fuel and the recommended amount of VICTORY Premium Carbon Clean Plus or other gasoline stabilizer, fill the fuel tank only to the top of the filler insert.
2. Start and run the engine for 15 minutes in a well ventilated area to pass the stabilized fuel through entire fuel-injection system.

Engine Component Protection

1. Change the engine oil (see page 81). You don't need to replace the oil filter at this time, but you must replace the oil filter when you remove the motorcycle from storage.

Caution

Carbon deposits, normally suspended in engine oil that is in service, settle on internal engine components during storage. Settled carbon deposits can cause engine damage.

2. Using pressurized air, blow any debris from the area around each spark plug.

WARNING

Wear face protection when using pressurized air.

3. Remove the spark plugs (see page 118). Pour one tablespoon of clean motor oil into each spark plug hole.
4. Connect the spark plugs to the spark plug wires and ground the spark plugs to the engine. With the main switch in the ON position, the stop/run switch set to RUN, and the transmission in neutral, press the electric starter button to crank the engine a few times. This procedure inhibits corrosion by coating the cylinder walls with the oil you poured in the spark plug holes.
5. Set the main switch to the OFF position and reinstall the spark plugs.

Tire Inflation

Inflate the tires to normal pressure (see page 114).

Battery Care

1. Remove the battery (see page 122).
2. To clean oxidation from the battery posts and cable connectors, use a wire brush. Wash the posts and cable connectors with a solution of 1 part baking soda to 16 parts water. Rinse with clean water and wipe dry. Apply a thin film of dielectric grease (available from your VICTORY dealer) to the posts and cable connectors.
3. Clean the outside of the battery with a solution of mild detergent and warm water.
4. Store the battery in a dry location that maintains a temperature of 32° to 90°F (0° to 32°C).
5. While in storage, fully charge the battery once a month (see page 123).

Park and Cover the Motorcycle

Park the motorcycle in its storage location. Cover the motorcycle with a genuine VICTORY motorcycle cover, or a cover made from a durable, breathable material designed for storage. Covering the motorcycle helps protect it from dust and other airborne materials. The cover must be of a breathable material to prevent moisture from building up on the motorcycle.

Maintenance During Storage

Check and maintain normal tire pressure (page 114) and battery voltage during storage.

STORAGE

Removal from Storage

1. Remove the cover and unlock the front forks (if locked with accessory lock).
2. Check the tire pressure (page 114) and inflate the tires if necessary.
3. Reinstall the battery (see page 124).
4. Wash and dry the entire motorcycle (see page 132).
5. Prior to starting the engine, change the engine oil and filter (see page 81, beginning with step 4).

Caution

During storage, temperature and humidity changes can cause condensation to form in the crankcase and mix with engine oil. Running the engine with oil that contains condensation can cause engine damage.

6. Wax, polish or apply protectant to the appropriate motorcycle components (see page 134).
7. Perform the pre-operation check as outlined on page 47.
8. Road test the motorcycle before returning it to regular use (see page 129).

Motorcycle Noise Regulation

Tampering with noise control systems is prohibited. Federal law prohibits the following acts or causing thereof:

- The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- The use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are:

- Removal or puncturing of the muffler, baffles, header pipes or any other component which conducts exhaust gases.
- Removal or puncturing of any part of the intake system.
- Lack of proper maintenance.
- Replacing any moving part of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

This product should be checked for repair or replacement if the motorcycle noise has increased significantly through use. Otherwise, the owner may become subject to penalties under state and local ordinances.

Noise Emission Warranty

VICTORY Motorcycle Division warrants that this exhaust system, at the time of sale, meets all applicable U.S. EPA Federal noise standards. This warranty extends to the first person who buys this exhaust system for purposes other than resale, and to all subsequent buyers. Warranty claims should be directed to: an authorized VICTORY dealer or VICTORY Motorcycle Division, Polaris Sales Inc., P.O. Box 47700, Hamel, MN 55340-9960

WARRANTIES

Emissions Control System Warranty

VICTORY Motorcycles, Polaris Sales Inc. - Emission Control System Warranty Statement

Your Warranty Rights and Obligations

The California Air Resources Board and VICTORY Motorcycle Division, Polaris Sales Inc. (hereinafter VICTORY) are pleased to explain the emission control system warranty on your 2004 or later VICTORY motorcycle. In California, new motor vehicles must be designed, built and equipped to meet the state's stringent anti-smog standards. VICTORY must warrant the emission control system on your motorcycle for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your motorcycle.

Your emission control system may include parts such as the fuel-injection system, the ignition system, catalytic converter and engine computer. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, VICTORY will repair your motorcycle at no cost to you, including diagnosis, parts and labor.

Manufacturer's Warranty Coverage

Class III motorcycles (280 cc and larger): for a period of use of five (5) years or 30,000 kilometers (18,641 miles), whichever first occurs.

If an emission-related part on your motorcycle is defective, the part will be repaired or replaced by VICTORY. This is your emission control system DEFECTS WARRANTY.

WARRANTIES

Owner's Warranty Responsibilities

As the motorcycle owner, you are responsible for the performance of the required maintenance listed in your owner's manual. VICTORY recommends that you retain all receipts covering maintenance on your motorcycle, but VICTORY cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your motorcycle to a VICTORY dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

As the motorcycle owner, you should be aware that VICTORY may deny your warranty coverage if your motorcycle or part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact VICTORY Motorcycle Division, Polaris Sales Inc., P.O. Box 47700, Hamel, Minnesota 55340-9960, or the California Air Resources Board, P.O. Box 8001, 9528 Telstar Avenue, El Monte, CA 91734-8001.

VICTORY Motorcycle Division, Polaris Sales Inc. - Limited Warranty on Emission Control System

VICTORY Motorcycle Division, Polaris Sales Inc., (hereinafter VICTORY) warrants that each new 2004 and later VICTORY Motorcycle that includes as standard equipment a headlight, taillight and stoplight, and is street legal:

- A. is designed, built and equipped so as to conform at the time of initial retail purchases with all applicable regulations of the United States Environmental Protection Agency, and the California Air Resources Board; and
- B. is free from defects in material and workmanship which cause such motorcycle to fail to conform with applicable regulations of the United States Environmental Protection Agency or the California Air Resources Board for a period of use, depending on the engine displacement, of 12,000 kilometers (7,456 miles), if the motorcycle's engine displacement is less than 170 cubic centimeters; of 18,000 kilometers (11,185 miles), if the motorcycle's engine displacement is equal or greater than 170 cubic centimeters but less than 280 cubic centimeters; or of 30,000 kilometers (18,641 miles), if the motorcycle's engine displacement is 280 cubic centimeters or greater; or 5 (five) years from the date of initial retail delivery, whichever occurs first.

WARRANTIES

I. Coverage

Warranty defects shall be remedied during customary business hours at any authorized VICTORY motorcycle dealer located within the United States of America in compliance with the Clean Air Act and applicable regulations of the United States Environmental Protection Agency and the California Air Resources Board. Any part or parts replaced under this warranty shall become the property of VICTORY.

In the State of California only, emission related warranted parts are specifically defined by the state's Emission Warranty Parts List. These warranted parts are: carburetor and internal parts; intake manifold; fuel tank; fuel injection system; spark advance mechanism; crankcase breather; air cutoff valves; fuel tank cap for evaporative emission controlled vehicles; oil filler cap; pressure control valve; fuel/vapor separator; canister; igniters; breaker governors; ignition coils; ignition wires; ignition points; condensers, and spark plugs if failure occurs prior to the first scheduled replacement; and hoses, clamps, fittings and tubing used directly in these parts. Since emission related parts may vary from model to model, certain models may not contain all of these parts and certain models may contain functionally equivalent parts.

In the State of California only, Emission Control System emergency repairs, as provided for in the California Administrative Code, may be performed by other than an authorized VICTORY dealer. An emergency situation occurs when an authorized VICTORY dealers is not reasonably available, a part is not available within 30 days, or a repair is not complete within 30 days. Any replacement part can be used in an emergency repair. VICTORY will reimburse the owner for expenses, including diagnosis, not to exceed VICTORY's suggested retail price for all warranted parts replaced and labor charges based on VICTORY's recommended time allowance for the warranty repair and the geographically appropriate hourly labor rate. The owner may be required to keep receipts and failed parts in order to receive compensation.

II. Limitations

This Emission Control System warranty shall not cover any of the following:

- A. Repair or replacement required as a result of:
 - (1) accident
 - (2) misuse
 - (3) repairs improperly performed or replacements improperly installed
 - (4) use of replacement parts or accessories not conforming to VICTORY specifications which adversely affect performance and/or
 - (5) use in competitive racing or related events.
- B. Inspections, replacement of parts, and other services and adjustments necessary for required maintenance
- C. Any motorcycle on which the odometer mileage has been changed so that actual mileage cannot be readily determined.

WARRANTIES

III. Limited Liability

A. The liability of VICTORY under this Emission Control System Warranty is limited solely to the remedying of defects in material or workmanship by an authorized VICTORY motorcycle dealer at its place of business during customary business hours. This warranty does not cover inconvenience or loss of use of the motorcycle or transportation of the motorcycle to or from the VICTORY dealer. VICTORY SHALL NOT BE LIABLE FOR ANY OTHER EXPENSES, LOSS OR DAMAGE, WHETHER DIRECT, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY ARISING IN CONNECTION WITH THE SALE OR USE OF OR INABILITY TO USE THE VICTORY MOTORCYCLE FOR ANY PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

B. NO EXPRESS EMISSION CONTROL SYSTEM WARRANTY IS GIVEN BY VICTORY EXCEPT AS SPECIFICALLY SET FORTH HEREIN. ANY EMISSION CONTROL SYSTEM WARRANTY IMPLIED BY LAW, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS LIMITED TO THE EXPRESS EMISSION CONTROL SYSTEM WARRANTY TERMS STATED IN THIS WARRANTY. THE FOREGOING STATEMENTS OF WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHER REMEDIES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

C. No dealer is authorized to modify this VICTORY Limited Emission Control System Warranty.

IV. Legal Rights

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

V. This Warranty Is In Addition To The VICTORY Limited Motorcycle Warranty.

VI. Additional Information.

Any replacement part that is equivalent in performance and durability may be used in the performance of any maintenance or repairs. However, VICTORY is not liable for these parts. The owner is responsible for the performance of all required maintenance. Such maintenance may be performed at a service establishment or by any individual. The warranty period begins on the date the motorcycle is delivered to an ultimate purchaser.

**VICTORY Motorcycle Division, Polaris Sales Inc.
P.O. Box 47700
Hamel, MN 55340-9960
ATTN: Warranty Department**

WARRANTIES

VICTORY Motorcycle Warranty Policy

Limited Warranty

VICTORY Motorcycle Division, Polaris Sales Inc., P.O. Box 47700, Hamel, Minnesota 55340-9960, gives a ONE YEAR LIMITED WARRANTY on all components of the VICTORY Motorcycle against defects in material or workmanship. This warranty covers the parts and labor charges for repair or replacement of defective parts which are covered by this warranty. This warranty begins on the date of purchase. This warranty is transferrable to another consumer during the warranty period through a VICTORY Motorcycle dealer.

Registration

At the time of sale, the Warranty Registration Form must be completed by your dealer and submitted to VICTORY Motorcycle Division, Polaris Sales Inc. within ten days. Upon receipt of this registration, VICTORY Motorcycle Division, Polaris Sales Inc. will record the registration for warranty. No verification of registration will be sent to the purchaser as the copy of the Warranty Registration Form will be the warranty entitlement. If you have not signed the original registration and received the “customer copy”, please contact your dealer immediately. **NO WARRANTY COVERAGE WILL BE ALLOWED UNLESS YOUR VICTORY MOTORCYCLE IS REGISTERED WITH VICTORY MOTORCYCLES DIVISION OF POLARIS SALES INC.**

Initial dealer preparation and set-up of your VICTORY Motorcycle is very important in ensuring trouble-free operation. Purchasing a motorcycle in the crate or without proper dealer set-up will void your warranty coverage.

WARRANTIES

Warranty Coverage And Exclusions:

Limitations Of Warranties And Remedies

The warranty excludes any failures that are not caused by a defect in material or workmanship. This warranty does not cover accidental damage, normal wear and tear, abuse or improper handling. This warranty also does not cover any VICTORY Motorcycle that has been altered structurally, modified, neglected, improperly maintained, used for racing, or used for purposes other than for which it was manufactured, or for any damages which occur during trailer transit or as a result of unauthorized service or the use of unauthorized parts. In addition, this warranty does not cover physical damage to paint or finish, stress cracks, tearing or puncturing of upholstery material, corrosion, or defects in parts, components or VICTORY Motorcycle due to fire, explosions or any other cause beyond VICTORY Motorcycle Division, Polaris Sales Inc. control.

This warranty does not cover the use of unauthorized lubricants, chemicals, or fuels that are not compatible with the VICTORY Motorcycle.

The exclusive remedy for breach of this warranty shall be, at VICTORY Motorcycle Division, Polaris Sales Inc. exclusive option, repair or replacement of any defective materials, or components or products. THE REMEDIES SET FORTH IN THIS WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON FOR BREACH OF THIS WARRANTY. VICTORY MOTORCYCLES DIVISION OF POLARIS SALES INC. SHALL HAVE NO LIABILITY TO ANY PERSON FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY DESCRIPTION, WHETHER ARISING OUT OF EXPRESS OR IMPLIED WARRANTY OR ANY OTHER CONTRACT, NEGLIGENCE, OR OTHER TORT OR OTHERWISE. Some states do not permit the exclusion or limitation of incidental or consequential damages or implied warranties, so the above limitations or exclusions may not apply to you if inconsistent with controlling state law.

WARRANTIES

ALL IMPLIED WARRANTIES (INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO THE ABOVE ONE YEAR WARRANTY PERIOD. VICTORY MOTORCYCLES DIVISION OF POLARIS SALES INC. FURTHER DISCLAIMS ALL EXPRESS WARRANTIES NOT STATED IN THIS WARRANTY OTHER THAN EMISSIONS AND EXCISE WARRANTIES. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you if inconsistent with controlling state law.

How To Obtain Warranty Service

If your VICTORY Motorcycle requires warranty service, you must take it to a VICTORY Motorcycle Servicing Dealer. When requesting warranty service you must present your copy of the Warranty Registration form to the dealer. (THE COST OF TRANSPORTATION TO AND FROM THE DEALER IS YOUR RESPONSIBILITY). VICTORY Motorcycles division of Polaris Sales Inc. suggests that you use your original selling dealer; however, you may use any VICTORY Motorcycle Servicing Dealer to perform warranty service.

Please work with your dealer to resolve any warranty issues. Should your dealer require any additional assistance they will contact the appropriate person at VICTORY Motorcycles division of Polaris Sales Inc.

This warranty also gives you specific legal rights, and you may also have other rights which vary from state to state.

If any of the above terms are void because of state or federal law, all other warranty terms will remain in effect.

Fuel Specifications

Use only unleaded gasoline, 92 pump octane minimum.

DO NOT USE GASOLINE CONTAINING METHANOL.

Using gasoline/methanol blends can result in poor starting and driveability, and may damage critical fuel system components.

Gasoline containing up to 15% Methyl Tertiary Butyl Ether (MTBE) can be used.

Gasoline containing up to 10% Ethanol can be used.

Gasoline that has been Reformulated or Oxygenated can be used.

Engine Oil Specifications

Polaris recommends the use of VICTORY Brand Synthetic Blend 20W-40 Motor Oil or equivalent.

Service Manual Available

You can purchase a genuine VICTORY 2004 VEGAS / KINGPIN / VEGAS ANSS Service Manual through your dealer. Order part number 9918961.

SPECIFICATIONS

Model Year 2004	KINGPIN
Dimensions	
Overall Length	99.1 in (251.9 cm)
Overall Width	38 in (97 cm)
Overall Height	50.75 in (129 cm)
Seat Height	26.5 in (67.3 cm)
Wheelbase	65.6 in (167 cm)
Ground Clearance	5.8 in (14.8 cm)
Rake/Trail	32.8° / 5.43 in. (13.8 cm)
Weight	
Dry Weight	639 lbs (290 kg)
Wet Weight	685 lbs (311 kg)
Gross Vehicle Weight Rating (GVWR)	1170 lbs (531 kg)
Capacities	
Engine Oil	6 Qt (5.7 Ltr)
Fuel	4.5 US Gal (17 Ltr)

NOTE: Dimensions and specifications may vary with features, options and accessories.

SPECIFICATIONS

Model Year 2004	KINGPIN
Engine	
Engine Model Number	MCVT1507D 2004
Configuration	50° V-Twin
Displacement	92 cu in (1507 cc)
Cooling System	Air & Oil
Compression Ratio	9.2:1
Valve Train	4 Valves Per Cylinder With Hydraulic Lifters
Bore and Stroke	97 x 102 mm
Throttle Body Bore	44 mm
Exhaust System	Dual-Staggered
Lubrication System	Wet Sump
Spark Plug / Gap	NGK CPR6EA-9 .032 in (0.8 mm)
Chassis	
Front Suspension Type/Travel	Inverted Telescopic Fork / 5.1 in (13 cm)
Rear Suspension Type/Travel	Single, Monotube Gas, Preload Adjustable / 3.9 in (10 cm)
Swingarm	Forged and Cast Aluminum With Rising Rate Linkage
Front Brakes	Single 300 x 5 mm Floating Rotor With 4 Piston Caliper
Rear Brakes	Single 300 x 5 mm Floating Rotor With 2 Piston Caliper

NOTE: Dimensions and specifications may vary with features, options and accessories.

SPECIFICATIONS

Model Year 2004		KINGPIN
Drive System		
Final Drive Type		Fiberglass Reinforced Belt
Transmission Type		5 speed - Constant Mesh
Primary Drive		Gear With Torque Compensator
Primary Reduction Ratio		1.5:1
Gear Shift Pattern		1 Down, 4 Up
Internal Gear Ratios	1st	3.2:1
	2nd	2.19:1
	3rd	1.53:1
	4th	1.24:1
	5th	1:1
Final Drive Ratio		2.13:1
Clutch Type		Wet Multi-Plate; Diaphragm Spring

NOTE: Dimensions and specifications may vary with features, options and accessories.

SPECIFICATIONS

Model Year 2004	KINGPIN
Wheels and Tires	
Front Wheel Type/Size	Cast, Billet, or Laced* 18 x 3.0
Rear Wheel Type Size	Cast, Billet, or Laced* 18 x 5.0
Front Tire Type/Size	Dunlop 491 Elite II (130/70 - B18 63H)
Rear Wheel Type/Size	Dunlop D417 (180/55-B18 74V)
Electrical	
Alternator	38 Amp Max Output
Battery	12 Volts 18 Amp Hour
Lights and Fuses	
Fuses Engine / ECM	15 amp
Fuel Pump	10 amp
Headlamp / Brake Lamp	15 amp
Tail Lamp, Flashers, Indicator Lamps, Horn	15 amp
Ignition / Gauges	15 amp
Bulbs Headlamp (International)	High: H8 / Low H11 (H4)
Taillight	Non-Serviceable LED
Turn Signal	R10W
Indicator	2.3 Watt Wedge Base

*** Cast and billet wheels are tubeless. Laced wheels require tubes.**

NOTE: Dimensions and specifications may vary with features, options and accessories.

IDENTIFICATION NUMBERS

Record important numbers below.

Vehicle Identification Number: _____

(Located on right side of steering head, see page 33)

Engine Identification Number: _____

(Located on top of crankcase behind rear cylinder, see page 34)

Ignition Key Number: _____

(Stamped on shaft of key, see page 34)

Model Number: _____

(Located on left side of steering head, see page 34)

INDEX

A

Accelerating	69
Accessory Selection and Installation	19
Air Filter	84
Axle Front	97
Axle Rear	95

B

Battery	121-124
Battery Charging	123
Battery Installation	124
Battery Removal	122
Brake Disc, Inspection	112
Brake Fluid	110
Brake Fluid Level	53-54, 107, 110
Brake Hoses	112
Brake Hoses and Lines	111
Brake Lever Lubrication	106
Brake Lever Movement	53, 106
Brake Pads	55, 112
Brake Pedal	44
Brake Pedal Freeplay	54, 109
Brake Pedal Freeplay	108
Brakes	53-54, 106-112
Braking	70
Break-in Period	61-65

C

Carrying a Passenger	12
Carrying Cargo	16
Check Engine Indicator	38
CLEANING	131-136
Clutch	56, 102-104
Clutch Freeplay	104
Clutch Lever	41
Clutch Lever and Cable	102
Clutch Lever Lubrication	103
COMPONENT IDENTIFICATION	30-34
Components, General	31-32
Components, Handlebar	30
Control Cable Lubrication	105
Crankcase Ventilation Hose	98

D

Defects	23
Drive Belt	58, 86-88
Drive Belt Condition	86
Drive Belt Tension	86-88
Drive Sprocket	85
Drive Sprocket Nut	85

E

Electrical Equipment	48-49
Emergency Flasher Switch	42
Emergency Flashers	49
Emissions Control System Warranty	142
Engine Break-in Period	61-65
Engine Compression	117

E

Engine Identification Number	34
Engine Oil	81-83
Engine Oil Level	50, 83
Engine Oil Specifications	151
Engine Stop/Run Switch	42, 49
Evaporative Emission Control System (California model only)	51
Evaporative Emission Control System (California models only)	98
Exhaust	20
Exhaust System	117

F

Fast Idle Lever	40, 56, 100
Fasteners	59, 129
FOREWORD	3
Fork Oil	96
Forks	96
Front Axle	97
Front Brake Lever	43
Front Brake Lever Movement	53
Fuel	20
Fuel Cap	45
Fuel Components	51
Fuel Filter	99
Fuel Hose	51
Fuel Hose, Rail and Connections	51, 98
Fuel Level	51
Fuel Specifications	151

INDEX

F

Fuel Stabilizer	138
Fuel System	98-99
Fuel System Priming	63
Fuel Tank, Removal/Installation	98
Fueling and Fill Height	63
Fuses	125

G

Gasoline	20
Gear Shift Pedal	44, 113
Gross Vehicle Weight Rating (GVWR)	14-15
GVWR Loading Example	15

H

Handlebar Controls, Left	40-41
Handlebar Controls, Right	42-43
Hazardous Materials, Handling	74
Headlamp	48
Headlamp Adjustment	128
Headlamp High Beam Indicator	38
Headlamp High/Low Beam Switch	40
Horn	49
Horn Button	41
Hoses and Connections	55

I

IDENTIFICATION NUMBERS	156
Ignition Key	35
Ignition Key Number	34
Ignition Switch	35
Indicator Lights	38, 48
Initial Maintenance	75
Instrument Cluster	36
INSTRUMENTS, FEATURES AND CONTROLS	35-46
INTRODUCTION	5

L

Low Fuel Indicator	39
Low Oil Pressure Indicator	39

M

MAINTENANCE	74-130
Maintenance	22
Maintenance Interval Table	76-78
Maintenance Record	79-80
Maintenance, Safety	21
Modifications	18

N

Neutral Indicator	38
Noise Emission Warranty	141
Noise Regulation	141

O

Odometer	36
Oil	81-83
Oil Change	81-82
Oil Filter	81-82
Oil Filter Change	81-82
Oil Level	50, 82-83
Oil Specifications	151
OPERATION	60-73
Out of Fuel, Procedures	63

P

Park Position (P)	35
Parking the Motorcycle	18, 72-73
Periodic Maintenance Intervals	75
PRE-OPERATION CHECK	47-59
Priming the Fuel System	63
Protective Apparel	13

R

Rear Shock Absorber	93
Recommended Oil	82
Recommended Shift Points	68
Registration	148
Removal from Storage	140
Repairing Painted Surface Damage ..	136
Road Test	129

INDEX

S

Saddlebag Care, Leather	136
Saddlebags	17
Safe Riding Practices	7-13
SAFETY	6-29
Safety/Vehicle Information Labels ..	24-29
Safety Defects	23
Seat Removal and Installation	120
Service Manual, Part Number	151
Shift Points	68
Shifting Gears	66-68
Shock Absorber	92-93
Side Covers	46
Sidestand	46, 59, 126-127
Sidestand Lubrication	127
Sidestand Pad	126
Spark Plugs	118-119
SPECIFICATIONS	151-155
Speedometer	36
Starter Button	43
Starting the Engine	64-65
Steering	57, 96-97
Stop/Run Switch	42, 49
Stopping the Engine	71
STORAGE	137-140
Suspension, Front	57, 96-97
Suspension, Rear	58, 92-95
Swing Arm	95
Symbols and Terms	6

T

TABLE OF CONTENTS	4
Tachometer (Optional)	37
Taillight / Brake Light	48
Test Drive	129
Throttle	101
Throttle Control Cable	101
Throttle Control Cables	55
Throttle Control Grip	43, 55, 101
Throttle Freeplay, Adjustment	101
Tire Condition	52, 115
Tire Pressure	52, 114
Tire Pressure Table	114
Tire Tread Depth	52, 115
Tires 52	114-115
Tool Universal	122
Transporting the Motorcycle	17
Trip Odometer	36
Turn Signal Indicators	39
Turn Signal Switch	41
Turn Signals	49

U

Universal Tool	122
----------------------	-----

V

Vehicle Identification Number	33
Victory Motorcycle Warranty Policy ..	148
VIN	33

W

WARRANTIES	141-150
Warranty, Owner's Responsibilities ..	143
Warranty Coverage and Exclusions ..	149
Warranty Policy	148
Washing and Drying the Motorcycle	132-133
Waxing, Polishing and Applying Protectants	134
Wheel Alignment, Rear	89-91
Wheel Spokes	116
Wheel, Rear	89-91
Windshield Care	135



POLARIS[®]
The Way Out.

For your nearest Polaris dealer, call 1-800-POLARIS
or visit www.polarisindustries.com

Polaris Sales Inc., 2100 Hwy. 55, Medina, MN 55340

Phone (763) 417-8650 Fax (763) 542-0599

Part No. 9919167

Printed in USA